

MaxiSys_Peugeot_V2.40 Function List (Note:For reference only)

NOTES:

- This function is supported. ✖ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|---------|----------------------------|--------------------|-----------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 107 | | 2005- | Driving assistance/Comfort | | Power steering | ● | ● | ● | ● | ○ | |
| 107 | | 2005- | Engine/Gearbox | Gearbox ECU | Controlled Manual | ○ | ● | ● | ● | | |
| 107 | | 2005- | Engine/Gearbox | Petrol | CFA BOSCH ME7.9.5 | ○ | ● | ● | ● | ● | |
| 107 | | 2005- | Engine/Gearbox | Diesel | 8HT SIEMENS SID805 | ● | ● | ● | ● | | |
| 107 | | 2005- | Vehicle protection/Managem | | Coded engine immobiliser | ○ | ● | ● | ● | ○ | |
| 107 | | 2005- | Active and passive safety | | ABS BOSCH 8.0 C1 | ○ | ● | ● | | ○ | |
| 107 | | 2005- | Active and passive safety | | ESP BOSCH 8.0 C1 | ○ | ● | ● | | | |
| 107 | | 2005- | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ○ | |
| 206 | 206/206MUX | 09-2001 | Active safety | | ABS MK70 | ● | ● | ● | ● | ● | 06001 |
| 206 | 206+ | 09-2001 | Active and passive safety | ABS or ESP ECU | ABS MK70 | ● | ● | ● | ● | ● | 06001 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | N6A BOSCH ME7.4.4 | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | NFU BOSCH ME7.4.4 | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | KFW BOSCH ME7.4.4 | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | N6A BOSCH ME7.4.4 FLEX FUEL | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | NFU BOSCH ME7.4.4 FLEX FUEL | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | KFW BOSCH ME7.4.4 FLEX FUEL | ● | ● | ● | ● | ● | 07011 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Diesel | WJY DCN2 | ● | ● | ● | ● | ● | 10002 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Diesel | RHY EDC15C2 | ● | ● | ● | ● | ● | 10002 |
| 206 | 206/206MUX | 09-2001 | | | Air bags | ● | ● | ● | ○ | ○ | 10003 |
| 206 | 206+ | 09-2001 | Active and passive safety | air-bag | air-bag | ● | ● | ● | ○ | ○ | 10003 |
| 206 | 206+ | 09-2001 | Active and passive safety | ABS or ESP ECU | ESP MK60 | ● | ● | ● | ● | | 05003, 06001 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | NFU BOSCH ME7.4.5 | ● | ● | ● | ● | ● | 07011, 10002 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|---------|---------------------------|-----------------------|-----------------------------------|-----------|------------|-------------|-----------|-------------|---------------------|
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | KFW BOSCH ME7. 4. 5 | ● | ● | ● | ● | ● | 07011, 10002 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Petrol | NFU Or N6A ME749 | ● | ● | ● | ● | ● | 07011, 12006 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Petrol | KFW ME749 | ● | ● | ● | ● | ● | 07011, 12006 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Petrol | KFW ME749 BIO ELEX | ● | ● | ● | ● | ● | 07011, 12006 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Petrol | TU5JP4ME745 | ● | ● | ● | ● | ● | 07011, 12006 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Diesel | 8HZ BOSCH EDC16C3 EUR04 | ● | ● | ● | ● | ● | 10002, 12006 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Diesel | 9HY BOSCH EDC16C3 EUR04 | ● | ● | ● | ● | ● | 10002, 12006 |
| 206 | 206/206MUX | 09-2001 | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | 03003, 10001 |
| 206 | 206+ | 09-2001 | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | 03003, 10001 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | | Diesel fuel additive control unit | ● | ● | ● | ● | ● | 04003, 04006, 04022 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Diesel | RHY BOSCH EDC15C2 | ● | ● | ● | ● | ● | 04012 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Petrol | EDC17C10_BR2 | ● | ● | ● | ● | ● | 04014, 04015 |
| 206 | 206/206MUX | 09-2001 | Active safety | | ESP MK60 | ● | ● | ● | ● | ● | 05005, 05012 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | KFW SAGEM S2000 | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | K6D SAGEM S2000 | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | RFN MM4. 8P | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | HFX MM4. 8P | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | KFW J34P | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | K6D J34P | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | NFU J35 | ● | ● | ● | ● | ● | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | | AL4 automatic gearbox | ● | | ● | ● | ● | 07011 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Petrol | N6A ME749 BIO FLEX | ● | ● | ● | ● | ● | 07011 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Petrol | KFW J34P | ● | ● | ● | ● | ● | 07011 |
| 206 | 206+ | 09-2001 | Engine/Gearbox | Engine ECU→ Petrol | HFX J34P | ● | ● | ● | ● | ● | 07011 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|---------|----------------------------------|-------------|---|-----------|------------|-------------|-----------|-------------|------------------|
| 206 | 206+ | 09-2001 | Engine/Gearbox | Gearbox ECU | AL4 automatic gearbox | ● | ● | ● | ● | | 07011 |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | 7LZ MM5NP | ● | ● | ● | ● | ● | 10002 |
| 206 | 206/206MUX | 09-2001 | | | Alarm | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Driver | | Display/Telematics (AMF) | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Driver | | Display/Telematics (RT3) | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Driver | | Radio | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Driver | | CD player | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Driver | | Instrument panel | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Driver information/Communication | | Switch unit under steering wheel (COM 2000) | ● | ● | ● | ● | ○ | |
| 206 | 206/206MUX | 09-2001 | Driver | | On-board navigation system | ● | ● | ● | ● | ○ | |
| 206 | 206/206MUX | 09-2001 | Visibility/Lighting | | Driving school | ● | ○ | ○ | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Visibility/Lighting | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 206 | 206/206MUX | 09-2001 | Control the openings | | Electric retractable roof | ● | ● | ● | ● | | |
| 206 | 206/206MUX | 09-2001 | | | Air conditioning | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Active safety | | Anti-lock brakes TEVES | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | KFU MM6LP | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | RFK MM6LP | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | RFN MM6LP | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | | | Electric pump unit (power steering) | ● | ● | ● | ● | ○ | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Petrol | NFU Or N6A or N6B ME749 BIO FLEX | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Diesel | 8HX/8HZ BOSCH EDC16C3 EUR3 | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Diesel | 8HZ BOSCH EDC16C3 EUR04 | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Diesel | 9HY BOSCH EDC16C3 EURO4 | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Diesel | 9HY BOSCH EDC16C3 | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Diesel | 9HZ BOSCH EDC16C3 | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Diesel | WJY LUCAS DCN2 | ● | ● | ● | ● | ● | |
| 206 | 206/206MUX | 09-2001 | Engines/automatic gearbox | Diesel | 9HT BOSCH EDC16C3 | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|---------|---------------------------------------|--------------------|----------------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 206 | 206+ | 09-2001 | Inform the driver/Audio/Communication | Display/Telematics | RT3 | ● | ● | ● | ● | ● | |
| 206 | 206+ | 09-2001 | Inform the driver/Audio/Communication | Display/Telematics | display | ● | ● | ● | ● | | |
| 206 | 206+ | 09-2001 | Driver | | Air conditioning | ● | ● | ● | ● | ● | |
| 206 | 206+ | 09-2001 | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ○ | |
| 206 | 206+ | 09-2001 | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| 206 | 206+ | 09-2001 | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ● | | |
| 206 | 206+ | 09-2001 | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| 206 | 206+ | 09-2001 | Vehicle protection/Management | | Alarm | ● | ● | ● | ○ | | |
| 206 | 206+ | 09-2001 | Visibility/Lighting | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 207 | 207VAN/207i | 2007- | Active and passive safety | ABS or ESP ECU | ABS MK70 | ● | ● | ● | ● | ● | 06001 |
| 207 | 207CAN | 2007- | Active and passive safety | ABS or ESP ECU | ABS MK70.1 | ● | ● | ● | ● | ● | 06001 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Diesel | WJY DCN2 | ● | ● | ● | ● | ● | 10002 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Diesel | RHY EDC15C2 | ● | ● | ● | ● | ● | 10002 |
| 207 | 207VAN/207i | 2007- | Active and passive safety | air-bag | air-bag | ● | ● | ● | ○ | ○ | 10003 |
| 207 | 207CAN | 2007- | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ○ | 10003 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Diesel | 8HZ BOSCH EDC16C3 EURO4 | ● | ● | ● | ● | ● | 12006 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Diesel | 9HY BOSCH EDC16C3 EURO4 | ● | ● | ● | ● | ● | 12006 |
| 207 | 207VAN/207i | 2007- | Active and passive safety | ABS or ESP ECU | ESP MK60 | ● | ● | ● | ● | | 05003, 06001 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Petrol | KFV J34P | ● | ● | ● | ● | ● | 07011, 12006 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Petrol | N6A ME749 BIO FLEX | ● | ● | ● | ● | ● | 07011, 12006 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Petrol | KFW ME749 | ● | ● | ● | ● | ● | 07011, 12006 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Petrol | KFW ME749 BIO ELEX | ● | ● | ● | ● | ● | 07011, 12006 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Petrol | TU5JP4ME745 | ● | ● | ● | ● | ● | 07011, 12006 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|---------------------------------------|--------------------|----------------------------------|-----------|------------|-------------|-----------|-------------|--|
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Diesel | 8HZ BOSCH EDC16C3 EURO4 | ● | ● | ● | ● | ● | 10002, 12006 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Diesel | 9HY BOSCH EDC16C3 EURO4 | ● | ● | ● | ● | ● | 10002, 12006 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Diesel | 9HX BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Diesel | 9HZ BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Diesel | 9HV BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Diesel | 9HY BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Diesel | 9HT BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Petrol | N6A BOSCH ME7. 4. 5 | ● | ● | ● | ● | ● | 07011, 12006, 10002 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Petrol | N6B BOSCH ME7. 4. 5 | ● | ● | ● | ● | ● | 07011, 12006, 10002 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Petrol | NFU BOSCH ME7. 4. 5 | ● | ● | ● | ● | ● | 07011, 12006, 10002 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Petrol | KFU MMGLPC | ● | ● | ● | ● | ● | 07011, 12006, 10002 |
| 207 | 207CAN | 2007- | Driving assistance/Comfort | | Under inflation detection | ● | ● | ● | ● | ○ | 02001, 02002, 02003, 02004, 02009, 02010, 02011, 02012 |
| 207 | 207CAN | 2007- | | | Built-in systems interface (BSI) | ● | ● | ● | ● | ● | 03001, 03004, 10001 |
| 207 | 207VAN/207i | 2007- | | | Built-in systems interface (BSI) | ● | ● | ● | ● | ● | 03003, 10001 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Diesel | EDC17C10 BR2 | ● | ● | ● | ● | ● | 04014, 04015, 04017, 04019 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Diesel | EDC17C10 | ● | ● | ● | ● | ● | 04014, 04015, 04019 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Diesel | HDI SID807 | ● | ● | ● | ● | ● | 04014, 04015, 04019 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Petrol | EDC17C10_BR2 | ● | ● | ● | ● | ● | 04015, 04016 |
| 207 | 207CAN | 2007- | Active and passive safety | ABS or ESP ECU | ESP MK60-0 | ● | ● | ● | ● | ● | 05005, 05012 |
| 207 | 207CAN | 2007- | Engine/Gearbox | | AL4 automatic gearbox | ● | ● | ● | ● | ● | 07011 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Petrol | 5FX MED17. 4 | ● | ● | ● | ● | ● | 07011 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Petrol | 5FY MED17. 4 | ● | ● | ● | ● | ● | 07011 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Petrol | 5FW MEV17. 4 | ● | ● | ● | ● | ● | 07011 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Petrol | 8FS MEV17. 4 | ● | ● | ● | ● | ● | 07011 |
| 207 | 207CAN | 2007- | Engine/Gearbox | Petrol | MEV17. 4EVO | ● | ● | ● | ● | ● | 07011 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Petrol | NFU Or N6A ME749 | ● | ● | ● | ● | ● | 07011 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Petrol | KFW J34P | ● | ● | ● | ● | ● | 07011 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Engine ECU→ Petrol | HFX J34P | ● | ● | ● | ● | ● | 07011 |
| 207 | 207VAN/207i | 2007- | Engine/Gearbox | Gearbox ECU | AL4 automatic gearbox | ● | ● | ● | ● | | 07011 |
| 207 | 207CAN | 2007- | Engine/Gearbox | | Controlled manual gearbox (BVMP) | ● | ● | ● | ● | ● | 12006 |
| 207 | 207VAN/207i | 2007- | Inform the driver/Audio/Communication | Display/Telematics | RT3 | ● | ● | ● | ● | ● | |
| 207 | 207VAN/207i | 2007- | Inform the driver/Audio/Communication | Display/Telematics | display | ● | ● | ● | ● | | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|---------------------------------------|-------------|--|-----------|------------|-------------|-----------|-------------|------------------|
| 207 | 207CAN | 2007- | Driving assistance/Comfort | | Parking assistance | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Driving assistance/Comfort | | Air conditioning | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Driving assistance/Comfort | | Power steering | ● | ● | ● | ● | ○ | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | | Multi-function display | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ○ | ● | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | | Hands Free Kit | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | Telematics | Data communication ECU | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | Telematics | RNEG radio navigation | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | | Warning light showing seat belt not fastened | ● | ○ | ○ | ○ | ● | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | | High frequency receiver | ● | ● | ● | ● | ○ | |
| 207 | 207CAN | 2007- | Inform the driver/Audio/Communication | | Battery charge status unit | ● | ● | ● | ● | ○ | |
| 207 | 207CAN | 2007- | Engine/Gearbox | | Multiplexed additive adding pump ECU | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Vehicle protection/Managem | | Alarm | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Vehicle protection/Managem | | Retractable roof | ● | ● | ● | ● | ● | |
| 207 | 207CAN | 2007- | Visibility/Lightin | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 207 | 207CAN | 2007- | Visibility/Lightin | | Static AFS | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|---------------------------------------|------------------------------|----------------------------------|-----------|------------|-------------|-----------|-------------|---|
| 207 | 207CAN | 2007- | Visibility/Lighting/Signalling | | Driving school module | ● | ● | ○ | ○ | ● | |
| 207 | 207CAN | 2007- | Visibility/Lighting/Signalling | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| 207 | 207VAN/207i | 2007- | Driver information/Communication | | Air conditioning | ● | ● | ● | ● | ● | |
| 207 | 207VAN/207i | 2007- | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ○ | |
| 207 | 207VAN/207i | 2007- | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| 207 | 207VAN/207i | 2007- | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ● | | |
| 207 | 207VAN/207i | 2007- | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| 207 | 207VAN/207i | 2007- | Vehicle protection/Management | | Alarm | ● | ● | ● | ○ | | |
| 207 | 207VAN/207i | 2007- | Visibility/Lighting/Signalling | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 208 | | 2012- | | Built-in system | BSI2010 | ● | ● | ● | ● | ○ | 03003, 10001 |
| 208 | | 2012- | | Engine ECU | EDC17C10_BR2 | ● | ● | ● | ● | ● | 04009, 04015, 04016, 04017, 04019, 04021, 07001 |
| 208 | | 2012- | | Engine ECU | HDI_SID807_BR2 | ● | ● | ● | ● | ● | 04010, 04015, 04017, 04019, 04021, 07001 |
| 208 | | 2012- | | Diesel additive | POMPE_MUX_TI | ● | ● | ● | ● | ● | 04026 |
| 208 | | 2012- | | ABS or ESP | ABSMK100 | ● | ● | ● | ● | ● | 04027, 06007 |
| 208 | | 2012- | | ABS or ESP | ESPMK100 | ● | ● | ● | ● | ● | 04028, 05001, 06001 |
| 208 | | 2012- | | Engine ECU | MEV 17 4 2 | ● | ● | ● | ● | ● | 07011 |
| 208 | | 2012- | | Engine ECU | V46 | ● | ● | ● | ● | ● | 07011 |
| 208 | | 2012- | | Electric power | DAE | ● | ● | ● | ● | ○ | |
| 208 | | 2012- | | Battery change status | BECB_GEN2 | ● | ● | ● | ● | ○ | |
| 208 | | 2012- | | Rain sensor | PLUIE LUMINOSITE UDS | ● | ● | ● | ● | ○ | |
| 208 | | 2012- | | Radio | AUTORADIO | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Air bag | RBG UDS | ● | ● | ● | ● | ○ | |
| 208 | | 2012- | | Multiplexed control panel | FMUX | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Steering wheel with integral | VCI | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|--------------------------|--|-----------------|-----------|------------|-------------|-----------|-------------|------------------|
| 208 | | 2012- | | Independent telematic unit (BTA) | BTA | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Instrument panel | COMBINE_UDS | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Audio amplifier | AMPLI_AUDIO | ● | ● | ● | ○ | ● | |
| 208 | | 2012- | | Parking aid | AAS_UDS | ● | ● | ● | ● | ○ | |
| 208 | | 2012- | | Air conditioning | TDC_CH_MUX | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Air conditioning | TDC_RF_MUX | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Air conditioning | TDC_RFTA_MUX | ● | ● | ● | ● | ○ | |
| 208 | | 2012- | | gearbox | BVMP | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Voltage retaining device | DMTC | ● | ○ | ○ | ○ | ○ | |
| 208 | | 2012- | | Trailer relay unit | BSG_2010_RQ | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | CD player | CDE | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Telematics | SMEG | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Matrix screen integral to the instrument | MATT_C_2010 | ● | ● | ● | ○ | ● | |
| 208 | | 2012- | | Matrix screen integral to the instrument | MATT_M_2010 | ● | ● | ● | ○ | ● | |
| 208 | | 2012- | | Siren | SIR | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Anti-theft alarm | MUS | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Driving school module | MAE | ● | ● | ● | ○ | ● | |
| 208 | | 2012- | | Lighting relay unit | BSG_E | ● | ● | ● | ● | ● | |
| 208 | | 2012- | | Switch module under the steering wheel (top of column) | COM2008P | ● | ● | ● | ● | ● | |
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | Petrol | KFX BOSCH MP7.3 | | ● | ● | | ● | 07009 |
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | Petrol | LFY BOSCH MP7.3 | | ● | ● | | ● | 07009 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------|-----------------------|-----------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | Petrol | NFZ BOSCH MP7. 2 | | ● | ● | | ● | 07009 |
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | Petrol | KFW SAGEM S2000 | ● | | ● | ● | ● | 07011 |
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | Petrol | K6D SAGEM S2000 | ● | | ● | ● | ● | 07011 |
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | AL4 automatic gearbox | AL4 automatic gearbox | ● | ● | ● | ● | ● | 07011 |
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | Petrol | NFT BOSCH M7. 4. 4 | ● | ● | ● | ● | | |
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | Petrol | NFV BOSCH M7. 4. 4 | ● | ● | ● | ● | | |
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | Diesel | RHY BOSCH EDC15C2 | ● | ● | ● | ● | | |
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | Diesel | WJY LUCAS DCN2 | ● | ● | ● | ● | ● | |
| 306 | 306R | 1993-2002 | Engine/automatic gearbox | Diesel | WJZ LUCAS DCN2 | ● | ● | ● | ● | ● | |
| 306 | 306R | 1993-2002 | Active safety | | ABS BOSCH 5. 3 | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Active safety | | ABS BOSCH 5. 3 | | ● | ● | | | 06001 |
| 307 | 307VAN | 2001-2008 | Active safety | | ABS BOSCH 8 | ● | ● | ● | ● | ● | 06001 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | N6A BOSCH ME7. 4. 4 | ● | ● | ● | ● | ● | 07011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | NFU BOSCH ME7. 4. 4 | ● | ● | ● | ● | ● | 07011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | KFW SAGEM S2000 | ● | | ● | ● | ● | 07011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | K6D SAGEM S2000 | ● | | ● | ● | ● | 07011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | KFU MM6LP | ● | ● | ● | ● | ● | 07011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | RFK MM6LP | ● | ● | ● | ● | ● | 07011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | RFN MM6LP | ● | ● | ● | ● | ● | 07011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | KFU MM6LP | ● | ● | ● | ● | ● | 07011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | RFK MM6LP | ● | ● | ● | ● | ● | 07011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | RFN MM6LP | ● | ● | ● | ● | ● | 07011 |
| 307 | 307CAN | 2001-2008 | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ○ | 10003 |
| 307 | 307VAN | 2001-2008 | Driver | Display/Telem | RT3 | ● | ● | ● | ● | ● | 12006 |
| 307 | 307CAN | 2001-2008 | Active and passive safety | ABS or ESP ECU | ESP_BOSCH8 | ● | ● | ● | ● | ● | 06001, 05003 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------------------|----------------|--------------------------------------|-----------|------------|-------------|-----------|-------------|--|
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | N6A BOSCH ME7. 4. 5 | ● | ● | ● | ● | ● | 07011, 10002 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | NFU BOSCH ME7. 4. 5 | ● | ● | ● | ● | ● | 07011, 10002 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | NFU Or N6A Or N6B ME7. 4. 9 | ● | ● | ● | ● | ● | 07011, 12005 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | NFU Or N6A Or N6B ME7. 4. 9 BIO FLEX | ● | ● | ● | ● | ● | 07011, 12005 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | | AL4 gearbox | ● | | ● | ● | ● | 11001, 07011 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | RFK MM6LP | ● | ● | ● | ● | ● | 07010, 10002, 12006 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | RFN MM6LP | ● | ● | ● | ● | ● | 07010, 10002, 12006 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | RFJ MM6LPB | ● | ● | ● | ● | ● | 07010, 10002, 12006 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | NFU BOSCH ME7. 4. 5 | ● | ● | ● | ● | ● | 07011, 12004, 10004 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | 9HV BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04012, 04013, 12004, 12006, 10002 |
| 307 | 307CAN | 2001-2008 | Driving assistance/Comfort | | Under inflation detection | ● | ● | ● | ● | ○ | 02001, 02002, 02003, 02004, 02008, 02010 |
| 307 | 307CAN | 2001-2008 | | | Built-in systems interface (BSI) | ● | ● | ● | ● | ● | 03003, 03004, 10001 |
| 307 | 307VAN | 2001-2008 | | | Built-in systems interface (BSI) | ● | ● | ● | ● | ● | 03004, 03003, 10001 |
| 307 | 307CAN | 2001-2008 | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | 03004, 09011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | RHR SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | RHL SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015, 9001 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | | Diesel fuel additive control unit | ● | ● | ● | ● | ● | 04003, 04006, 04022 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | | Diesel fuel additive control unit | ● | ● | ● | ● | ● | 04004, 04005, 04016, 04022, 04025 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | RHL DCM3. 4 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | RHR DCM3. 4 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | RHR SIEMENS SID 803 | ● | ● | ● | ● | ● | 04014, 04015, 12006 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | RHL SIEMENS SID 803 | ● | ● | ● | ● | ● | 04014, 04015, 12006 |
| 307 | 307CAN | 2001-2008 | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ● | 05003 |
| 307 | 307CAN | 2001-2008 | Visibility/Lighting/Signalling | | Steering wheel switching module. | ● | ● | ● | ● | ● | 05003 |
| 307 | 307VAN | 2001-2008 | Active safety | | ESP BOSCH 5. 7 | ● | ● | ● | ● | ● | 05005, 05012 |
| 307 | 307VAN | 2001-2008 | Active safety | | ESP BOSCH 8 | ● | ● | ● | ● | ● | 05005, 05012 |
| 307 | 307CAN | 2001-2008 | Active and passive safety | ABS or ESP ECU | ABS8. 1 | ● | ● | ● | ● | ● | 06001 |
| 307 | 307CAN | 2001-2008 | Active and passive safety | ABS or ESP ECU | ESP8. 1 | ● | ● | ● | ● | ● | 06001, 05006, 05012 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------------------|----------------|---|-----------|------------|-------------|-----------|-------------|-----------------------------------|
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | RFN MM48P (Mechanical throttle housing) | ● | ● | ● | ● | ● | 07011 |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Petrol | RFN MM4MP2 (Motorised butterfly) | ● | ● | ● | ● | ● | 07011 |
| 307 | 307CAN | 2001-2008 | Driving assistance/Comfort | | Parking assistance | ● | ● | ● | ● | ● | 08001 |
| 307 | 307CAN | 2001-2008 | Inform the driver/Audio/Communication | | Telematics | ● | ● | ● | ● | ● | 09012, 09013, 09014, 09015 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | RFJ MM6KP Bio Flex (EW10AFF) | ● | ● | ● | ● | ● | 09017, 07011, 12005, 12006, 10002 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | | AM6 automatic gearbox | ● | ● | ● | ● | ● | 11001, 12001, 12002, 12003 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | 9HX BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04012, 04013, 12004, 12006, 10002 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | 9HZ BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04012, 04013, 12004, 12006, 10002 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | 9HT BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04012, 04013, 12004, 12006, 10002 |
| 307 | 307CAN | 2001-2008 | Active and passive safety | ABS or ESP ECU | ABS8_BOSCH | ● | ● | ● | ● | ● | 06001 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | KFU MM6LP | ● | ● | ● | ● | ● | 07010, 10002, 12006 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | | AL4 automatic gearbox | ● | ● | ● | ● | ● | 07011, 11001, 11002 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | N6A BOSCH ME7.4.5 | ● | ● | ● | ● | ● | 07011, 12004, 10004 |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | N6B BOSCH ME7.4.5 | ● | ● | ● | ● | ● | 07011, 12004, 10004 |
| 307 | 307CAN | 2001-2008 | Driving assistance/Comfort | | Air conditioning | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Driving assistance/Comfort | | Power steering | ● | ● | ● | ● | ○ | |
| 307 | 307CAN | 2001-2008 | Inform the driver/Audio/Communication | | Multi-function display | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ○ | ● | |
| 307 | 307CAN | 2001-2008 | Inform the driver/Audio/Communication | | Hands Free Kit | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Petrol | RFU MM6LPC | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | RHY BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | RHZ BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | 9HY BOSCH EDC15C3 EUR03 | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | Diesel | 9HY BOSCH EDC15C3 EUR04 | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Engine/Gearbox | | Multiplexed additive adding pump ECU | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Vehicle protection/Managem | | Alarm | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Vehicle protection/Managem | | Driver's door module | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|------------------------------|---------------|---|-----------|------------|-------------|-----------|-------------|------------------|
| 307 | 307CAN | 2001-2008 | Vehicle protection/Managem | | Passenger door module | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Vehicle protection/Managem | | Retractable roof | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Vehicle protection/Managem | | Sun roof | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Visibility/Lightin | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 307 | 307CAN | 2001-2008 | Visibility/Lightin | | Right headlamp beam corrector | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Visibility/Lightin | | Left headlamp beam corrector | ● | ● | ● | ● | ● | |
| 307 | 307CAN | 2001-2008 | Visibility/Lightin | | Driving school moduel | ● | ● | ● | ○ | ● | |
| 307 | 307VAN | 2001-2008 | | | Alarm | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Driver | Display/Telem | AMF | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Driver | | Parking assistance | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Driver | | Radio | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Driver | | CD player | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Driver | | Instrument panel | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Driver information/Communica | | Switch unit under steering wheel (COM 2000) | ● | ● | ● | ● | ○ | |
| 307 | 307VAN | 2001-2008 | Visibility/Lightin | | Driving school | ● | ○ | ○ | ● | ○ | |
| 307 | 307VAN | 2001-2008 | Visibility/Lightin | | Switch unit under steering wheel (COM 2000) | ● | ● | ● | ● | ○ | |
| 307 | 307VAN | 2001-2008 | | | Air bags | ● | ● | ● | ○ | ○ | |
| 307 | 307VAN | 2001-2008 | | | Roll-over ECU | ● | ● | ● | ● | ○ | |
| 307 | 307VAN | 2001-2008 | Control the openings | | Driver's door module | ● | ● | ● | ● | ○ | |
| 307 | 307VAN | 2001-2008 | Control the openings | | Passenger door module | ● | ● | ● | ● | ○ | |
| 307 | 307VAN | 2001-2008 | Control the openings | | Retractable roof | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Control the openings | | Sun roof | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | | | Air conditioning | ● | ● | ● | ● | | |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | 8HZ BOSCH EDC16C3 | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | 9HX BOSCH EDC16C3 | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | 9HY BOSCH EDC16C3 EURO4 | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | 9HZ BOSCH EDC16C3 | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | RHS BOSCH EDC15C2 | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------------------|-------------------|-------------------------------------|-----------|------------|-------------|-----------|-------------|--|
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | RHY BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | RHZ BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | RHY SIEMENS SID 801 | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | Engine/automatic gearbox | Diesel | 9HT BOSCH EDC16C3 | ● | ● | ● | ● | ● | |
| 307 | 307VAN | 2001-2008 | | | Electric pump unit (power steering) | ● | ● | ● | ● | ○ | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | 03007 |
| 308 | | 2007- | Active and passive safety | ABS or ESP ECU | ABS 8.1 | ● | ● | ● | ● | ● | 06001 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Petrol | 5FT MED17.4 | ● | ● | ● | ● | ● | 07011 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Petrol | 5FW MEV17.4 | ● | ● | ● | ● | ● | 07011 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Petrol | 5FX MED17.4 | ● | ● | ● | ● | ● | 07011 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Petrol | 5FY MED17.4 | ● | ● | ● | ● | ● | 07011 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Petrol | 8FS MEV17.4 | ● | ● | ● | ● | ● | 07011 |
| 308 | | 2007- | Engine /Gearbox | gearbox | AL4 gearbox | ● | ● | ● | ● | ● | 07011 |
| 308 | | 2007- | Active and passive safety | air-bag | air-bag | ● | ● | ● | ● | ○ | 10003 |
| 308 | | 2007- | Engine /Gearbox | gearbox | AM6 Euro5 automatic gearbox | ● | ● | ● | ● | ● | 12006 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Petrol | N6A ME745 | ● | ● | ● | ● | ● | 07010, 10002, 12006 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Petrol | N6B ME745 | ● | ● | ● | ● | ● | 07010, 10002, 12006 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Petrol | NFU ME745 | ● | ● | ● | ● | ● | 07010, 10002, 12006 |
| 308 | | 2007- | Driving assistance/Comfort | | Under inflation detection | ● | ● | ● | ● | ○ | 02001, 02002, 02003, 02004, 02005, 02006, 02007, 02009, 02010, 02012 |
| 308 | | 2007- | Built-in systems interface (BSI) | | Built-in systems interface (BSI) | ● | ● | ● | ● | ● | 03001, 03004, 10001 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Diesel | DCM3.5 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04019, 04020, 04021 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Diesel | RHF DCM3.4 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Diesel | RHL DCM3.4 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→Diesel | RHR DCM3.4 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|---------------------------------------|--------------------|----------------------------------|-----------|------------|-------------|-----------|-------------|----------------------------|
| 308 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | EDC17C10_BR2 | ● | ● | ● | ● | ● | 04014, 04015, 04017, 04019 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | HDI_SID807_BR2 | ● | ● | ● | ● | ● | 04014, 04015, 04017, 04019 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | HDI_SID807 | ● | ● | ● | ● | ● | 04014, 04015, 04019 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | 9HV BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | 9HX BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | 9HY BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | 9HZ BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 308 | | 2007- | Engine /Gearbox | Multiplexed | POMPE_MUX_TI | ● | ● | ● | ● | ● | 04026 |
| 308 | | 2007- | Active and passive safety | ABS or ESP ECU | ESP 8.1 | ● | ● | ● | ● | ● | 05006, 06001 |
| 308 | | 2007- | Engine /Gearbox | gearbox | CFC300P gearbox | ● | ● | ● | ● | ● | 12006 |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→ Petrol | NFU ME749 Bio Flex | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→ Petrol | RFJ MM6KP Bio Flex(EW10AFF) | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Engine /Gearbox | Engine ECU→ Petrol | RFJ MM6LPB | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Engine /Gearbox | gearbox | AM6C gearbox | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Engine /Gearbox | gearbox | AT6 Euro5 automatic gearbox | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Inform the driver/Audio/Communication | Telematics | Data communication ECU | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Inform the driver/Audio/Communication | Telematics | RNEG radio navigation | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Driving assistance/Comfort | | air conditioning | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Vehicle protection/Managem | | Alarm | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | Audio amplifier | ● | ● | ● | ○ | ● | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | Battery charge status unit. | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ○ | ● | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | Control panel dot matrix display | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-----------------|-----------|---------------------------------------|-------------|--|-----------|------------|-------------|-----------|-------------|------------------|
| 308 | | 2007- | Visibility/Lighting/Signalling | | discharge bulbs vertical and horizontal adjustment | ● | ● | ● | ● | | |
| 308 | | 2007- | Driving assistance/Comfort | | driver seat memory unit | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Vehicle protection/Management | | Driver's door control panel | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Visibility/Lighting | | Driving school module | ● | ● | ○ | ○ | ● | |
| 308 | | 2007- | Driving assistance/Comfort | | Electropump assembly | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | Hands Free Kit | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Driving assistance/Comfort | | Lane departure warning | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | multifunction screen | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Engine /Gearbox | | multiplexed additive adding pump | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | not fastened warning light(TNB) | ● | ○ | ○ | ○ | | |
| 308 | | 2007- | Driving assistance/Comfort | | Parking assistance | ● | ● | ● | ● | ○ | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | radio | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Visibility/Lighting | | rain sensor | ● | ● | ● | ○ | ○ | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | Service module | ● | ● | ● | ● | ● | |
| 308 | | 2007- | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Diesel | 4HX BOSCH EDC15C2 | | ● | ● | | | 04012 |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Diesel | RHY BOSCH EDC15C2 | | ● | ● | | | 04012 |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Diesel | RHZ BOSCH EDC15C2 | | ● | ● | | | 04012 |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Diesel | RHS BOSCH EDC15C2 | ● | ● | ● | ● | ● | 04012 |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | | Diesel fuel additive control unit | ● | ● | ● | ● | ● | 04022 |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Petrol | R6F MM4. 8P | ● | ● | ● | ● | ● | 07009, 07011 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-----------------|-----------|---------------------------|-------------------|------------------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Petrol | RFN MM4. 8P | ● | ● | ● | ● | ● | 07009, 07011 |
| 406 | 406 | 1995-2004 | Engines/automatic gearbox | Automatic gearbox | AL4 autoadaptive automatic gearbox | ● | ● | ● | ● | ● | 07011 |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Automatic gearbox | AL4 autoadaptive automatic gearbox | ● | | ● | ● | ● | 07011 |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Petrol | 6FZ SAGEM S2000 | ● | | ● | ● | ● | 07011 |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Petrol | 6FZ SAGEM S2000 | ● | | ● | ● | ● | 07011 |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Petrol | XFZ BOSCH ME7. 4. 6 | ● | | ● | ● | ● | 07011 |
| 406 | 406 | 1995-2004 | Air bags | | Air bag and seat belt | | ● | ● | | | |
| 406 | 406 | 1995-2004 | Air bags | | Side airbag. (right side) | | ● | ● | | | |
| 406 | 406 | 1995-2004 | Active safety | | Electronically managed suspension | | ● | ● | | | |
| 406 | 406 | 1995-2004 | Active safety | | ABS BOSCH | | ● | ● | | | |
| 406 | 406 | 1995-2004 | Active safety | | ABS BOSCH 5. 3 | ● | ● | ● | ● | ● | |
| 406 | 406 | 1995-2004 | Engines/automatic gearbox | Petrol | LFX MM1AP | | ● | ● | | ● | |
| 406 | 406 | 1995-2004 | Engines/automatic gearbox | Petrol | LFY BOSCH MP7. 3 | | ● | ● | | ● | |
| 406 | 406 | 1995-2004 | Engines/automatic gearbox | Petrol | LFY SAGEM SL 96 | | ● | ● | | | |
| 406 | 406 | 1995-2004 | Engines/automatic gearbox | Petrol | XFZ BOSCH MP7. 0 | | ● | ● | | | |
| 406 | 406 | 1995-2004 | Engines/automatic gearbox | Diesel | RHZ BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 406 | 406 | 1995-2004 | Engines/automatic gearbox | Diesel | RHZ BOSCH EDC15C2 | | ● | ● | ● | ● | |
| 406 | 406 | 1995-2004 | Air bags | | Side airbag. (left side) | | ● | ● | | | |
| 406 | 406 COUPE | 1995-2004 | Air bags | | Air bag and seat belt | | ● | ● | ○ | ○ | |
| 406 | 406 COUPE | 1995-2004 | Air bags | | Side airbag. (right side) | | ● | ● | ○ | | |
| 406 | 406 COUPE | 1995-2004 | Active safety | | BOSCH ABS5 | | ● | ● | | | |
| 406 | 406 COUPE | 1995-2004 | Active safety | | BOSCH ABS5. 3 | | ● | ● | | ● | |
| 406 | 406 COUPE | 1995-2004 | Engines/automatic gearbox | Automatic gearbox | AL4 autoadaptive automatic gearbox | ● | ● | ● | ● | ● | |
| 406 | 406 COUPE | 1995-2004 | Air bags | | Side airbag. (left side) | | ● | ● | ○ | | |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Petrol | 3FZ MM4MP2 | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Petrol | 6FZ SAGEM S2000 | ● | | | ● | | |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Petrol | RLZ SIEMENS SIRIUS 81 | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Petrol | LFY BOSCH MP7. 3 | | ● | ● | | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-----------------|-----------|----------------------------------|-------------------|---------------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Petrol | R6F MM4. 8P | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Petrol | RFR MM4. 8P | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Petrol | RFN MM4. 8P | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Petrol | XFZ BOSCH ME7. 4. 6 | ● | | ● | ● | ● | |
| 406 | 406R/406R COUPE | 06-2001 | | | Built-in systems interface(BSI) | | ● | ● | ● | | |
| 406 | 406R/406R COUPE | 06-2001 | Driver information/Communication | | Multi-function display | ● | ● | ● | ● | | |
| 406 | 406R/406R COUPE | 06-2001 | Driver information/Communication | | Radio | ● | ● | ● | ● | | |
| 406 | 406R/406R COUPE | 06-2001 | Driver information/Communication | | CD player | ● | ● | ● | ● | | |
| 406 | 406R/406R COUPE | 06-2001 | Driver information/Communication | | Instrument panel | | ● | ● | | | |
| 406 | 406R/406R COUPE | 06-2001 | Driver information/Communication | | On-board navigation system | ● | ● | ● | ● | ○ | |
| 406 | 406R/406R COUPE | 06-2001 | Air bags | | Air bag and seat belt | | ● | ● | ○ | ○ | |
| 406 | 406R/406R COUPE | 06-2001 | Air bags | | Side airbag. (right side) | | ● | ● | ○ | | |
| 406 | 406R/406R COUPE | 06-2001 | | | Air conditioning | | ● | ● | | | |
| 406 | 406R/406R COUPE | 06-2001 | Engine/automatic gearbox | Automatic gearbox | 4HP20 automatic gearbox | ● | ● | ● | ● | | |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Petrol | 3FZ MM4MP2 | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Petrol | RLZ IDE SIRIUS 81 | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Diesel | 4HX BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | | | Alarm | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | Driver information/Communication | | Multi-function display | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | Driver information/Communication | | Instrument panel | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-----------------|-----------|----------------------------------|-------------------|--|-----------|------------|-------------|-----------|-------------|--|
| 406 | 406R/406R COUPE | 2001-2004 | Driver information/Communication | | Radio | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | Driver information/Communication | | CD player | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | Driver information/Communication | | On-board navigation system | ● | ● | ● | ● | ○ | |
| 406 | 406R/406R COUPE | 2001-2004 | Driver information/Communication | | Switch unit under steering wheel(COM 2000) | ● | ● | ● | ● | ○ | |
| 406 | 406R/406R COUPE | 2001-2004 | Visibility/lighting | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 406 | 406R/406R COUPE | 2001-2004 | | | Air bags | ● | ● | ● | ○ | ○ | |
| 406 | 406R/406R COUPE | 2001-2004 | | | Air conditioning | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 06-2001 | Air bags | | Side airbag. (left side) | | ● | ● | ○ | | |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | | Diesel fuel additive control unit | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Automatic gearbox | 4HP20 automatic gearbox | ● | ● | ● | ● | | |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Automatic gearbox | AL4 autoadaptive automatic gearbox | ● | | ● | ● | ● | |
| 406 | 406R/406R COUPE | 06-2001 | Active safety | | ABS BOSCH 5.3 | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | Active safety | | ABS BOSCH 5.3 | ● | ● | ● | ● | ● | |
| 406 | 406R/406R COUPE | 2001-2004 | Engine/automatic gearbox | Diesel | RHY SIEMENS SID 801 | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Driving assistance/Comfort | | Under inflation detection | ● | ● | ● | ● | ○ | 02002, 02003, 02004, 02010, 02012 |
| 407 | | 2004-2010 | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | 03003, 03004 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | RHL SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | RHL SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015 |
| 407 | | 2004-2010 | Engine/Gearbox | | Diesel fuel additive control unit | ● | ● | ● | ● | ● | 04004, 04005, 04022, 04029 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | UHZ SIEMENS SID 201 | ● | ● | ● | ● | ● | 04008, 04010, 04014, 04015, 04020, 04021 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | RHL DCM3.4 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04018, 04020, 04021 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | RHR DCM3.4 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04018, 04020, 04021 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | RHF DCM3.4 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04018, 04020, 04021 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | RHF DCM3.5 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04019, 04020, 04021 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | 4HP BOSCH EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------------------|-----------------------|------------------------------------|-----------|------------|-------------|-----------|-------------|--|
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | 4HR BOSCH EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | 4HS BOSCH EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | 4HT BOSCH EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | 9HY BOSCH EDC16C3 EURO3 | ● | ● | ● | ● | | 04014, 04015 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | 9HZ BOSCH EDC16C3 | ● | ● | ● | ● | | 04014, 04015 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | 9HT BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015 |
| 407 | | 2004-2010 | Engine/Gearbox | Diesel | EDC17CP11 | ● | ● | ● | ● | ● | 04014, 04015, 07002 |
| 407 | | 2004-2010 | Active and passive safety | <u>ABS or ESP ECU</u> | ESP_EBC_440_K | ● | ● | ● | ● | | 05002, 05005, 05012, 06001 |
| 407 | | 2004-2010 | Active and passive safety | <u>ABS or ESP ECU</u> | ESP8.1 | ● | ● | ● | ● | | 05003, 06001 |
| 407 | | 2004-2010 | Active and passive safety | <u>ABS or ESP ECU</u> | ESP_EBC_440_CAN | ● | ● | ● | ● | | 05005, 05012, 06001 |
| 407 | | 2004-2010 | Engine/Gearbox | Petrol | RFJ MM6LPB | ● | ● | ● | ● | ● | 07011 |
| 407 | | 2004-2010 | Engine/Gearbox | Petrol | 3FY MM6LPB | ● | ● | ● | ● | ● | 07011 |
| 407 | | 2004-2010 | Engine/Gearbox | Petrol | 6FY MM6LPB | ● | ● | ● | ● | ● | 07011 |
| 407 | | 2004-2010 | Engine/Gearbox | Petrol | 6FZ S2000PM2 | | ● | ● | | | 07011 |
| 407 | | 2004-2010 | Engine/Gearbox | Petrol | RFJ MM6KP Bio Flex(EW10AFF) | ● | ● | ● | ● | ● | 07011 |
| 407 | | 2004-2010 | Driving assistance/Comfort | | Parking assistance | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Driving assistance/Comfort | | Drivers seat memory unit | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Driving assistance/Comfort | | Passenger seat memorisation module | ● | ● | ● | ● | | |
| 407 | | 2004-2010 | Driving assistance/Comfort | | Air conditioning | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Driving assistance/Comfort | | Additional heating | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Driving assistance/Comfort | | Power steering | ● | ● | ● | ● | | |
| 407 | | 2004-2010 | Driving assistance/Comfort | | Controlled suspension | ● | ● | ● | ● | | |
| 407 | | 2004-2010 | Driving assistance/Comfort | | battery charge statue unit | ● | ● | ● | ● | ○ | |
| 407 | | 2004-2010 | Inform the driver/Audio/Communication | | Multi-function display | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ○ | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------------------|--------------------|----------------------------------|-----------|------------|-------------|-----------|-------------|--|
| 407 | | 2004-2010 | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Inform the driver/Audio/Communication | | Hands Free Kit | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Inform the driver/Audio/Communication | Telematics | Data communication ECU | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Inform the driver/Audio/Communication | Telematics | RNEG radio navigation | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Engine/Gearbox | | AM6 automatic gearbox | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Engine/Gearbox | | AL4 automatic gearbox | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Engine/Gearbox | | 4HP20 automatic gearbox | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Engine/Gearbox | | AM6 Euro5 automatic gearbox | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Engine/Gearbox | Petrol | XFV ME7.4.7 | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Engine/Gearbox | Petrol | 3FZ MM6LP | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Engine/Gearbox | Petrol | RFN MM6LP | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Vehicle protection/Managem | | Alarm | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Vehicle protection/Managem | | Drivers's door module | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Vehicle protection/Managem | | Passenger door module | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Vehicle protection/Managem | | Sun roof | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ○ | |
| 407 | | 2004-2010 | Visibility/Lightin | | Control unit Windscreen | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Visibility/Lightin | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 407 | | 2004-2010 | Visibility/Lightin | | Master discharge bulb | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Visibility/Lightin | | Slave discharge bulb | ● | ● | ● | ● | ● | |
| 407 | | 2004-2010 | Visibility/Lighting/Signalling | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| 408 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | DCM3.5 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04019, 04020, 04021 |
| 408 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | EDC17C10_BR2 | ● | ● | ● | ● | ● | 04014, 04015, 04017, 04019 |
| 408 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | HDI_SID807_BR2 | ● | ● | ● | ● | ● | 04014, 04015, 04017, 04019 |
| 408 | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | HDI_SID807 | ● | ● | ● | ● | ● | 04014, 04015, 04019 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|----------------------------|----------------------------------|---|-----------|------------|-------------|-----------|-------------|--|
| 408 | | 2007- | Engine /Gearbox | Multiplexed additive adding pump | POMPE_MUX_TI | ● | ● | ● | ● | ● | 04026 |
| 607 | 607R | 1999-2010 | Driving assistance/Comfort | | Under inflation detection | ● | ● | ● | ● | ○ | 02002, 02003, 02004, 02006, 02010, 02011, 02012 |
| 607 | 607R | 1999-2010 | | | Built-in systems interface (BSI) | ● | ● | ● | ● | ● | 03001, 03004 |
| 607 | 607R | 1999-2010 | Engine/Gearbox | | Diesel fuel additive control unit | ● | ● | ● | ● | ● | 04004, 04005 |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Diesel | UHZ SIEMENS SID 803 | ● | ● | ● | ● | ● | 04004, 04014, 04015, 04016, 04025 |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Diesel | RHL SIEMENS SID 803 | ● | ● | ● | ● | ● | 04004, 04014, 04015, 04016, 04025 |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Diesel | 4HP BOSCH EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Diesel | 4HR BOSCH EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Diesel | 4HS BOSCH EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Diesel | 4HT BOSCH EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Diesel | UHZ SIEMENS SID 201 | ● | ● | ● | ● | ● | 04014, 04015 |
| 607 | 607R | 1999-2010 | Active and passive safety | | ESP_BOSCH8 | ● | ● | ● | ● | ● | 05003 |
| 607 | 607 | 1999-2010 | Engine/automatic gearbox | Petrol | 3FZ MM4MP2 | ● | ● | ● | ● | ● | 07010 |
| 607 | 607 | 1999-2010 | Engine/automatic gearbox | Petrol | RFN MM4MP2 (Motoresed butterfly) | ● | ● | ● | ● | ● | 07010 |
| 607 | 607 | 1999-2010 | Engine/automatic gearbox | Petrol | RFN MM48P (Mechanical throttle housing) | ● | ● | ● | ● | ● | 07011 |
| 607 | 607 | 1999-2010 | Engine/automatic gearbox | Petrol | R6F mm4. 8P | ● | ● | ● | ● | ● | 07011 |
| 607 | 607 | 1999-2010 | Engine/automatic gearbox | Petrol | XFX BOSCH ME7. 4. 6 | ● | ● | ● | ● | ● | 07011 |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Petrol | 3FZ MM6LP | ● | ● | ● | ● | ● | 07011 |
| 607 | 607 | 1999-2010 | | | Built-in systems interface (BSI) | ● | ● | ● | ● | ● | |
| 607 | 607 | 1999-2010 | Driver | | Multi-function display | | ● | ● | | | |
| 607 | 607 | 1999-2010 | Driver | | Parking assistance | ● | ● | ● | ● | | |
| 607 | 607 | 1999-2010 | Driver | | Radio | ● | ● | ● | ● | | |
| 607 | 607 | 1999-2010 | Driver | | CD player | ● | ● | ● | ● | | |
| 607 | 607 | 1999-2010 | Driver | | Instrument panel | ● | ● | ● | ● | | |
| 607 | 607 | 1999-2010 | Driver | | Radio telephone | ● | ● | ● | ● | ○ | |
| 607 | 607 | 1999-2010 | Driver | | Hands Free Kit | | ● | ● | | | |
| 607 | 607 | 1999-2010 | Driver | | On-board navigation system | ● | ● | ● | ● | ○ | |
| 607 | 607 | 1999-2010 | Visibility/Lighting | | Headlamp height corrector | | ● | ● | | | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------------------|-------------|-----------------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 607 | 607 | 1999-2010 | | | Air bags | ● | ● | ● | ○ | ○ | |
| 607 | 607 | 1999-2010 | Control the openings | | Motorised Boot ECU | ● | ● | ● | ● | | |
| 607 | 607 | 1999-2010 | Control the openings | | Driver's door control panel | | ● | ● | | | |
| 607 | 607 | 1999-2010 | Control the openings | | Passenger's door control panel | | ● | ● | | | |
| 607 | 607 | 1999-2010 | | | Air conditioning | | ● | ● | | | |
| 607 | 607 | 1999-2010 | Engine/automatic gearbox | Diesel | 4HX BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 607 | 607 | 1999-2010 | Engine/automatic gearbox | Diesel | RHS BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 607 | 607 | 1999-2010 | Engine/automatic gearbox | Diesel | RHZ BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 607 | 607 | 1999-2010 | Engine/automatic gearbox | | Diesel fuel additive control unit | ● | ● | ● | ● | | |
| 607 | 607 | 1999-2010 | Engine/automatic gearbox | | 4HP20 gearbox | ● | ● | ● | ● | | |
| 607 | 607 | 1999-2010 | | | Storing of the driving position | ● | ● | ● | ● | | |
| 607 | 607 | 1999-2010 | Active safety | | ABS BOSCH 5.3 | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Driving assistance/Comfort | | Parking assistance | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Driving assistance/Comfort | | Drivers seat memory unit | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Driving assistance/Comfort | | Air conditioning | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Driving assistance/Comfort | | Power steering | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Driving assistance/Comfort | | Controlled suspension | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Inform the driver/Audio/Communication | | Multi-function display | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ○ | ● | |
| 607 | 607R | 1999-2010 | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------------------|-------------|------------------------------------|-----------|------------|-------------|-----------|-------------|--|
| 607 | 607R | 1999-2010 | Inform the driver/Audio/Communication | | Hands Free Kit | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Inform the driver/Audio/Communication | | Telematics | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Engine/Gearbox | | AM6 automatic gearbox | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Engine/Gearbox | | 4HP20 automatic gearbox | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Petrol | XFV ME747 | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Petrol | 3FY MM6LPB | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Diesel | 4HX BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Engine/Gearbox | Diesel | RHS BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Vehicle protection/Managem | | Alarm | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Vehicle protection/Managem | | Motorised Boot ECU | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Vehicle protection/Managem | | Driver's door module | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Vehicle protection/Managem | | Passenger door module | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ○ | |
| 607 | 607R | 1999-2010 | Visibility/Lightin | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 607 | 607R | 1999-2010 | Visibility/Lightin | | Automatic headlamps corrector | ● | ● | ● | ● | ● | |
| 607 | 607R | 1999-2010 | Visibility/Lighting/Signalling | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| 806 | | 1994-2002 | Engines/automatic gearbox | Petrol | RFV BOSCH MP7.3 | ○ | ● | ● | ○ | ● | 07009 |
| 806 | | 1994-2002 | Engines/automatic gearbox | Petrol | RFN MM4.8P | ● | ● | ● | ● | ● | 07011 |
| 806 | | 1994-2002 | Engines/automatic gearbox | Petrol | R6F MM4.8P | ● | ● | ● | ● | ● | 07011 |
| 806 | | 1994-2002 | Engines/automatic gearbox | | AL4 autoadaptive automatic gearbox | ● | ○ | ● | ● | ● | 07011 |
| 806 | | 1994-2002 | Active safety | | BOSCH ABS5.3 | ● | ● | ● | ● | ○ | |
| 806 | | 1994-2002 | Engines/automatic gearbox | Diesel | RHW BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 806 | | 1994-2002 | Engines/automatic gearbox | Diesel | RHZ BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Driving assistance/Comfort | | Under inflation detection | ● | ● | ● | ● | ○ | 02002, 02003, 02004, 02006, 02011, 02012 |
| 807 | 807CAN | 2002- | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | 03001 |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | RHR SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015 |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | RHL SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015 |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | RHK SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|---------------------------------------|----------------|-----------------------------------|-----------|------------|-------------|-----------|-------------|--|
| 807 | 807CAN | 2002- | Engine/Gearbox | | Diesel fuel additive control unit | ● | ● | ● | ● | ● | 04004, 04005, 04022, 04029 |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | DCM3.5 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04019, 04020, 04021 |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | 4HP EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | 4HR EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | 4HS EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | 4HT EDC16CP39 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04020, 04021, 07004, 07005, 07008 |
| 807 | 807CAN | 2002- | Active and passive safety | ABS or ESP ECU | ESP 8.1 | ● | ● | ● | ● | ● | 05003, 05006 |
| 807 | 807CAN | 2002- | Active and passive safety | ABS or ESP ECU | ESP_BOSCH8 | ● | ● | ● | ● | ● | 05012 |
| 807 | 807CAN | 2002- | Engine/Gearbox | Petrol | RFJMM6LPB | ● | ● | ● | ● | ● | 07010 |
| 807 | 807CAN | 2002- | Engine/Gearbox | BVA AL4 | AL4 Automatic gearbox | ● | ● | ● | ● | ● | 07011 |
| 807 | 807CAN | 2002- | Engine/Gearbox | BVA AM6C | AM6C Automatic gearbox | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | 4HW BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | RHM BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | RHT BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Engine/Gearbox | Diesel | RHW BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Driving assistance/Comfort | | Parking assistance | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Driving assistance/Comfort | | Additional heating | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Driving assistance/Comfort | | Drivers seat memory unit | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Driving assistance/Comfort | | Air conditioning | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Driving assistance/Comfort | | Power steering | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Inform the driver/Audio/Communication | | Multi-function display | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Inform the driver/Audio/Communication | | Warning lights/odometer unit | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ○ | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|---------------------------------------|---------------|----------------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 807 | 807CAN | 2002- | Inform the driver/Audio/Communication | | Telematic receiver control | ● | ○ | ○ | ● | ○ | |
| 807 | 807CAN | 2002- | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Inform the driver/Audio/Communication | | Hands Free Kit | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Inform the driver/Audio/Communication | Telematics | Data communication ECU | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Inform the driver/Audio/Communication | Telematics | RNEG radio navigation | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Vehicle protection/Management | | Alarm | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Vehicle protection/Management | | Driver's door module | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Vehicle protection/Management | | Passenger door module | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Vehicle protection/Management | | Front sunroof | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Vehicle protection/Management | | Rear sunroof | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Vehicle protection/Management | | Middle sunroof | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ○ | |
| 807 | 807CAN | 2002- | Visibility/Lighting | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 807 | 807CAN | 2002- | Visibility/Lighting | | Right headlamp beam corrector | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Visibility/Lighting | | Left headlamp beam corrector | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Visibility/Lighting/Signalling | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| 807 | 807CAN | 2002- | Vehicle protection/Management | | Sliding side door module | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | | | Built-in systems interface (BSI) | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | | | Alarm | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Driver | Display/Telem | AMF | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Driver | Display/Telem | RT3 | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|----------------------------------|-------------|--|-----------|------------|-------------|-----------|-------------|------------------|
| 807 | 807VAN | 2002- | Driver information/Communication | | Radio/telematic receiver control | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Driver | | Parking assistance | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Driver information/Communication | | Warning lights and odometer ECU | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Driver | | Instrument panel | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Driver | | CD player | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Driver information/Communication | | Switch unit under steering wheel(COM 2000) | ● | ● | ● | ● | ○ | |
| 807 | 807VAN | 2002- | Visibility/Lighting | | Switch unit under steering wheel(COM 2000) | ● | ● | ● | ● | ○ | |
| 807 | 807VAN | 2002- | Visibility/Lighting | | Right headlamp beam corrector | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Visibility/Lighting | | Left headlamp beam corrector | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | | | Air bags | ● | ● | ● | ● | ○ | |
| 807 | 807VAN | 2002- | Control the openings | | Driver's door module | ● | ● | ● | ● | ○ | |
| 807 | 807VAN | 2002- | Control the openings | | Passenger door module | ● | ● | ● | ● | ○ | |
| 807 | 807VAN | 2002- | Control the openings | | Sliding door module | ● | ● | ● | ● | | |
| 807 | 807VAN | 2002- | Control the openings | | Front sunroof | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Control the openings | | Rear sunroof | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Control the openings | | Middle sunroof | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Air conditioning | | Climate control | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | | | Storing of the driving position | ● | ● | ● | ● | | |
| 807 | 807VAN | 2002- | | | Additional heating | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Petrol | RFN MM48P (Mechanical throttle housing) | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Petrol | R6F MM4.8P | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Petrol | 3FZ MM4MP2 | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Petrol | RFN MM4MP2 (Motorised butterfly) | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Petrol | 3FZ MM6LP | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------------------|-------------------|---|-----------|------------|-------------|-----------|-------------|---|
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Petrol | RFN MM6LP | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Petrol | XFW BOSCH ME746 | ● | | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Diesel | RHW BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Diesel | RHM BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Diesel | RHT BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Diesel | 4HW BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | | Diesel fuel additive control unit:ADDITIF_FAP | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | | Diesel fuel additive control unit:ADDGO2 | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Automatic gearbox | 4HP20 automatic gearbox | ● | ● | ● | ● | | |
| 807 | 807VAN | 2002- | Engines/automatic gearbox | Automatic gearbox | AL4 automatic gearbox | ● | | ● | ● | ● | |
| 807 | 807VAN | 2002- | Active safety | | ABR BOSCH 5.7 | ● | ● | ● | ● | ● | |
| 807 | 807VAN | 2002- | Active safety | | ESP BOSCH 5.7 | ● | ● | ● | ● | | |
| 1007 | 1007 CAN | 2004-2009 | Driving assistance/Comfort | | Under inflation detection | ● | ● | ● | ● | ○ | 02002, 02003, 02004, 02006, 02008, 02011, 02012 |
| 1007 | 1007 CAN | 2004-2009 | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | 03002, 10001 |
| 1007 | 1007 VAN | 2004-2009 | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | 03002, 10001 |
| 1007 | 1007 CAN | 2004-2009 | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | 03004 |
| 1007 | 1007 CAN | 2004-2009 | Engine/Gearbox | Diesel | 9HZ BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 1007 | 1007 CAN | 2004-2009 | Engine/Gearbox | Diesel | 9HT BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04014, 04015, 04020 |
| 1007 | 1007 CAN | 2004-2009 | Active and passive safety | | ESP MK60-0 | ● | ● | ● | ● | ● | 05005, 05012 |
| 1007 | 1007 CAN | 2004-2009 | Engine/Gearbox | | Controlled manual gearbox (BVMP) | ● | ● | ● | ● | ● | 07006 |
| 1007 | 1007 CAN | 2004-2009 | Engine/Gearbox | Petrol | KFU MM6LPC | ● | ● | ● | ● | ● | 07010 |
| 1007 | 1007 CAN | 2004-2009 | Engine/Gearbox | Petrol | KFV J34P | ● | ● | ● | ● | ● | 07011 |
| 1007 | 1007 CAN | 2004-2009 | Engine/Gearbox | Petrol | KFW J34P | ● | ● | ● | ● | ● | 07011 |
| 1007 | 1007 CAN | 2004-2009 | Active and passive safety | | ABS MK70.1 | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Active and passive safety | | ESP_MK60 | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ○ | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------------------|--------------------|--------------------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 1007 | 1007 CAN | 2004-2009 | Driving assistance/Comfort | | Parking assistance | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Driving assistance/Comfort | | Air conditioning | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Driving assistance/Comfort | | Power steering | ● | ● | ● | ● | ○ | |
| 1007 | 1007 CAN | 2004-2009 | Engine/Gearbox | Petrol | NFU BOSCH ME7.4.5 | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Engine/Gearbox | Diesel | 8HX SID 806 DV4 | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Engine/Gearbox | | Multiplexed additive adding pump ECU | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Inform the driver/Audio/Communication | | Multi-function display | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ○ | ● | |
| 1007 | 1007 CAN | 2004-2009 | Inform the driver/Audio/Communication | | Hands Free Kit | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Inform the driver/Audio/Communication | | Telematics | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Inform the driver/Audio/Communication | | High frequency receiver | ● | ● | ● | ● | ○ | |
| 1007 | 1007 CAN | 2004-2009 | Vehicle protection/Managem | | Alarm | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Engine/Gearbox | Diesel | 8HZ SID 806 DV4 | ● | ● | ● | ● | ● | |
| 1007 | 1007 CAN | 2004-2009 | Visibility/Lightin | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 1007 | 1007 CAN | 2004-2009 | Vehicle protection/Managem | | Motorised sliding side doors | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Driving assistance/Comfort | | Air conditioning | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Driving assistance/Comfort | Power steering | Power steering DAE | ● | ● | ● | ● | ○ | |
| 1007 | 1007 VAN | 2004-2009 | Inform the driver/Audio/Communication | Display/Telematics | EMF | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Inform the driver/Audio/Communication | Display/Telematics | RT3 | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-----------|---------------------------------------|----------------|----------------------------------|-----------|------------|-------------|-----------|-------------|---|
| 1007 | 1007 VAN | 2004-2009 | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ○ | |
| 1007 | 1007 VAN | 2004-2009 | Engine/Gearbox | | Controlled manual gearbox (BVMP) | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Engine/Gearbox | Petrol | NFU ME744 | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Engine/Gearbox | Petrol | N6A BOSCH ME7.4.5 | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Engine/Gearbox | Petrol | N6B BOSCH ME7.4.5 | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Engine/Gearbox | Petrol | NFU BOSCH ME7.4.5 | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Engine/Gearbox | Petrol | KFU S2000MP2 | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Engine/Gearbox | Petrol | KFU MM6LP | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Engine/Gearbox | Petrol | KFV J34P | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Engine/Gearbox | Diesel | 8HX SIEMENS SID 804 | ● | ● | ● | ● | | |
| 1007 | 1007 VAN | 2004-2009 | Vehicle protection/Managem | | Alarm | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Engine/Gearbox | Diesel | 8HZ SIEMENS SID 804 | ● | ● | ● | ● | | |
| 1007 | 1007 VAN | 2004-2009 | Active and passive safety | | ABS MK70 | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Active and passive safety | | ESP MK60 | ● | ● | ● | ● | ● | |
| 1007 | 1007 VAN | 2004-2009 | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ○ | |
| 1007 | 1007 VAN | 2004-2009 | Visibility/Lightin | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 1007 | 1007 VAN | 2004-2009 | Visibility/Lighting/Signalling | | Steering wheel switching module. | ● | ● | ● | ● | ○ | |
| 1007 | 1007 VAN | 2004-2009 | Vehicle protection/Managem | | Sliding side doors module | ● | ● | ● | ● | | |
| 3008 | | 2009- | Driving assistance/Comfort | | Electric parking brake | ● | ● | ● | ● | | 01001, 01003, 01004, 01005 |
| 3008 | | 2009- | Driving assistance/Comfort | | Under inflation detection | ● | ● | ● | ● | ○ | 02002, 02003, 02004, 02006, 02008, 02011, 02012 |
| 3008 | | 2009- | Engine/Gearbox | Diesel | 9HZ BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04007, 04014, 04015, 04020 |
| 3008 | | 2009- | Engine/Gearbox | Diesel | DCM3.5 | ● | ● | ● | ● | | 04014, 04015 |
| 3008 | | 2009- | Engine/Gearbox | Diesel | HDI SID807 | ● | ● | ● | ● | ● | 04014, 04015, 04019 |
| 3008 | | | Active and passive safety | ABS or ESP ECU | ESP 8.1 | ● | ● | ● | ● | ● | 05004, 05006 |
| 3008 | | 2009- | Engine/Gearbox | Diesel | 5FX MED 17.4 | ● | ● | ● | ● | ● | 07011 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|---------------------------------------|------------------------------|---|-----------|------------|-------------|-----------|-------------|------------------|
| 3008 | | 2009- | Driving assistance/Comfort | | High head Vision. | ● | ● | ● | ● | | |
| 3008 | | 2009- | Driving assistance/Comfort | | Assistance in complying with the inter-vehicle(ARTIV) | ● | ● | ● | ● | ○ | |
| 3008 | | 2009- | Driving assistance/Comfort | | Lane departure warning | ● | ● | ● | ● | ● | |
| 3008 | | 2009- | Driving assistance/Comfort | | Air conditioning ECU | ● | ● | ● | ● | | |
| 3008 | | 2009- | Driving assistance/Comfort | | Parking assistance | ● | ● | ● | ● | ○ | |
| 3008 | | 2009- | Driving assistance/Comfort | | Electropump assembly | ● | ● | ● | ● | | |
| 3008 | | 2009- | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | 10001 |
| 3008 | | 2009- | Inform the driver/Audio/Communication | | Audio amplifier | ● | ● | ● | ● | | |
| 3008 | | 2009- | Inform the driver/Audio/Communication | Multi-function display (EMF) | EMF_A | ● | ● | ● | ● | | |
| 3008 | | 2009- | Inform the driver/Audio/Communication | Multi-function display (EMF) | EMF_C | ● | ● | ● | ● | | |
| 3008 | | 2009- | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | | |
| 3008 | | 2009- | Inform the driver/Audio/Communication | | Portable unit. | ● | ● | ● | ● | ● | |
| 3008 | | 2009- | Inform the driver/Audio/Communication | | Radio. | ● | ● | ● | ● | | |
| 3008 | | 2009- | Inform the driver/Audio/Communication | Telematics | RNEG radio navigation | ● | ● | ● | ● | ● | |
| 3008 | | 2009- | Inform the driver/Audio/Communication | | Service module | ● | ● | ● | ● | ● | |
| 3008 | | 2009- | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | | |
| 3008 | | 2009- | Inform the driver/Audio/Communication | | Control panel dot matrix display | ● | ● | ● | ● | ● | |
| 3008 | | 2009- | Inform the driver/Audio/Communication | | Battery charge status unit. | ● | ● | ● | ● | ○ | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|---------------------------------------|-------------------|--------------------------------------|-----------|------------|-------------|-----------|-------------|--|
| 3008 | | 2009- | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ● | | |
| 3008 | | 2009- | Engine/Gearbox | | CFC300P gearbox | ● | ● | ● | ● | ● | |
| 3008 | | 2009- | Engine/Gearbox | | AM6 Euro5 automatic gearbox | ● | ● | ● | ● | ● | |
| 3008 | | 2009- | Engine/Gearbox | | AT6 Euro5 automatic gearbox | ● | ● | ● | ● | | |
| 3008 | | 2009- | Engine/Gearbox | | Multiplexed additive adding pump ECU | ● | ● | ● | ● | ● | |
| 3008 | | 2009- | Vehicle protection/Managem | | Driver's door control panel | ● | ● | ● | ● | ● | |
| 3008 | | 2009- | Vehicle protection/Managem | | Alarm | ● | ● | ● | ● | | |
| 3008 | | 2009- | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ○ | |
| 3008 | | 2009- | Active and passive safety | | 8.1 ESP | ● | ● | ● | ● | ● | |
| 3008 | | 2009- | Active and passive safety | | Anti-lock brakes BENDIX | ● | ● | ○ | ● | | |
| 3008 | | 2009- | Active and passive safety | | Network isolation unit | ● | ○ | ○ | ● | ○ | |
| 3008 | | 2009- | Visibility/Lightin | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| 3008 | | 2009- | Visibility/Lightin | | Windscreen wiper | ● | ● | ● | ● | | |
| 3008 | | 2009- | Visibility/Lightin | | Headlamp height corrector | ● | ● | ● | ● | | |
| 4007 | | | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | 03004, 03007 |
| 4007 | | | Engine/Automatic Gearbox/Transmission | Engine ECU/Diesel | 4HN EDC16CP39 | ● | ● | ● | ● | ● | 04001, 04014, 04015, 04016, 04018, 04023, 07002, 07004, 07005, 07007 |
| 4007 | | | Engine/Automatic Gearbox/Transmission | Engine ECU/Diesel | EDC16CP39_EUR05 | ● | ● | ● | ● | ● | 04001, 04014, 04015, 04016, 04018, 04023, 07002, 07004, 07005, 07007 |
| 4007 | | | Active and passive safety | ABS or ESP ECU | ESP | ● | ● | ● | ● | ● | 05008 |
| 4007 | | | Active and passive safety | ABS or ESP ECU | ABS | ● | ● | ● | ● | ● | |
| 4007 | | | Driving assistance/Comfort | | Air conditioning | ● | ● | ● | ● | ● | |
| 4007 | | | | | Built-in system | ● | ● | ● | ● | ● | |
| 4007 | | | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| 4007 | | | Inform the driver/Audio/Communication | | Navigation | ● | ● | ● | ○ | ○ | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|---------------------------------------|------------------------------|--------------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 4007 | | | Inform the driver/Audio/Communication | | Hands Free Kit | ● | ● | ● | ● | ● | |
| 4007 | | | Engine/Automatic Gearbox/Transmission | Engine ECU/Petrol | SFZ MIVEC | ● | ● | ● | ● | ● | |
| 4007 | | | Engine/Automatic Gearbox/Transmission | Gearbox | CVT gearbox | ● | ● | ● | ● | ○ | |
| 4007 | | | Engine/Automatic Gearbox/Transmission | Gearbox | DCT controlled gearbox | ● | ● | ● | ● | ● | |
| 4007 | | | Engine/Automatic Gearbox/Transmission | | 4x4 transmission | ● | ● | ● | ● | ● | |
| 4007 | | | Vehicle protection/Management | | Coded immobiliser | ● | ● | ● | ● | ○ | |
| 4007 | | | Vehicle protection/Management | | Driver's door control panel | ● | ● | ● | ● | ○ | |
| 4007 | | | Vehicle protection/Management | | Passenger's door control panel | ● | ● | ● | ● | ○ | |
| 4007 | | | Vehicle protection/Management | | Rear left door control pad | ● | ● | ● | ● | ○ | |
| 4007 | | | Vehicle protection/Management | | Rear right door control pad | ● | ● | ● | ● | ○ | |
| 4007 | | | Vehicle protection/Management | | Sun roof | ● | ● | ● | ● | ○ | |
| 4007 | | | Active and passive safety | | Air bag | ● | ● | ● | ● | ● | |
| 4007 | | | Active and passive safety | | steering wheel angle sensor | ● | ● | ● | ○ | ○ | |
| 4008 | 4008 | 2012- | | Parking aid | AAS MMC | ● | ● | ● | ● | ○ | |
| 4008 | 4008 | 2012- | | ABS/traction control | ABS_4x4 | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | ABS/traction control | ESP_4x4 | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Driver and passenger airbags | SAC_TRW | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Driver's door module | PDPC | ● | ● | ● | ● | ○ | |
| 4008 | 4008 | 2012- | | Rain and brightness sensor | CDPL | ● | ● | ● | ● | ○ | |
| 4008 | 4008 | 2012- | | Anti-theft alarm | ALARME MMC | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Power | EPS | ● | ● | ● | ● | ○ | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|---------------------------|--------------------------------------|-------------------|-----------|------------|-------------|-----------|-------------|----------------------------|
| 4008 | 4008 | 2012- | | Instrument panel | COMBINE | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Starting authorisation ECU | OSS | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Radio or radiotelephone (radio part) | AUTORADIO_3 | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Injection/ignition | MIVEC | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Injection/ignition | CMM_4A92 | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Injection/ignition | HDI_4N13 | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Rear final drive piloted clutch | TRANSMISSION | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Directional headlamps | CORPRO | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Locking and immobiliser control | WCM | ● | ● | ● | ● | ○ | |
| 4008 | 4008 | 2012- | | Locking and immobiliser control | KOS | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | Calculateur stop and | STT_MMC | ● | ● | ● | ● | ○ | |
| 4008 | 4008 | 2012- | | Streeing wheel angle | CAV | ● | ● | ● | ○ | ○ | |
| 4008 | 4008 | 2012- | | heating/ventilation | CLIM_REGULEE | ● | ● | ● | ● | ● | |
| 4008 | 4008 | 2012- | | gearbox | BV_CVT | ● | ● | ● | ● | ○ | |
| 4008 | 4008 | 2012- | | built-in Systems Interface | BSI | ● | ● | ● | ● | ● | 10001 |
| 4008 | 4008 | 2012- | | Navigation | NAVIGATION | ● | ● | ● | ○ | ○ | |
| 4008 | 4008 | 2012- | | Injection/ignition | HDI_SID807_J3J4 | ● | ● | ● | ● | ● | |
| 5008 | | 2009- | Engine/Gearbox | Diesel | 9HZ BOSCH EDC16C3 | ● | ● | ● | ● | ● | 04007, 04014, 04015, 04020 |
| 5008 | | 2009- | Engine/Gearbox | Diesel | HDI_SID807 | ● | ● | ● | ● | ● | 04014, 04015, 04019 |
| 5008 | | | Active and passive safety | ABS or ESP ECU | ESP 8.1 | ● | ● | ● | ● | ● | 05004, 05006 |
| 3008 HYbrid4 | | 2010- | | Parking aid | ASS | ● | ● | ● | ● | ○ | |
| 3008 HYbrid4 | | 2010- | | ABS or ESP | ESP81 | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Multifunction display | EMF_A | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|------|--|------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 3008 HYbrid4 | | 2010- | | Multifunction display | EMF_C | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Airbag | SAC AUTOLIV | ● | ● | ● | ● | ○ | |
| 3008 HYbrid4 | | 2010- | | Anti-theft alarm | ALARME | ● | ● | ● | ○ | ● | |
| 3008 HYbrid4 | | 2010- | | Radio amplifier | AMPLI_AUDIO | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Radio | AUTORADIO | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Radio | RD45 | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Battery charge status | BECEB_GEN2 | ● | ● | ● | ● | ○ | |
| 3008 HYbrid4 | | 2010- | | Built-in System Interface | BSI | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | MCP piloted manual gearbox (hybrid) | CFC300P_HY | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Engine relay unit | BSM | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Trailer relay unit | BSR | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | CD player | CHANGEUR CD | ● | ● | ● | ○ | ● | |
| 3008 HYbrid4 | | 2010- | | Air conditioning ECU | CLIM_REGULEE | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Instrument panel | COMBINE | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Rain sensor | PLUIE LUMINOSITE | ● | ● | ● | ○ | ○ | |
| 3008 HYbrid4 | | 2010- | | Power steering electric pump | GEP | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Windscreen wiper | MOTEV | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Electric secondary brake | FSE | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Switch module under the steering wheel (top of column) | HDC | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Engine ECU | DCM35 HY | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Hands-free kit | BOITIER_NOMADE | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|-------|------|--|------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 3008 HYbrid4 | | 2010- | | Matrix screen integral to the instrument | MATT | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Services module | MD_SERV | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Services module | BTA | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Services module | BLVV | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Multiplexed additive adding pump | PADDGO_E5 | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Driver's door module | PDPC | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Telematics | RADIONAV NG4 | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | High Head Vision | VTH | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Hybird mode selector | MCM | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Traction battery ECU | TBMU | ● | ● | ● | ● | ● | |
| 3008 HYbrid4 | | 2010- | | Hybrid control ECU 2 | HCU2 | ● | ● | ● | ● | ○ | |
| 3008 HYbrid4 | | 2010- | | Hybrid control ECU 1 | HCU1 | ● | ● | ● | ● | ○ | |
| 308 4 portes | | 2010- | | Multifunction display | EMF_A | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Multifunction display | EMF_C | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Anti-thdft alarm | | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Engine relay unit | BSM | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Rain and brightness sensor | PLUIE_LUMINOSITE | ● | ● | ● | ○ | ○ | |
| 308 4 portes | | 2010- | | Injection/ignition | DCM3.5_BR2 | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Injection/ignition | MED17_4_EURO4 | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Injection/ignition | MEV17_4_EURO4 | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Injection/ignition | ME749_EC5 | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Injection/ignition | MEV17_4_EURO5 | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|------------------|-------------|-------|------|--|-------------------|-----------|------------|-------------|-----------|-------------|--|
| 308 4 portes | | 2010- | | Injection/ignition | MED17_4_EURO5 | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Injection/ignition | MED17_4_2 | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Servces | BLVV | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Telematics | RADIONAV RNEG ECO | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Telematics | RNEG2010 | ● | ● | ● | ● | ● | |
| 308 4 portes | | 2010- | | Battery charge status | BECEB_GEN2 | ● | ● | ● | ● | ○ | |
| 308 4 portes | | 2010- | | Voltage retaining device | DMTC | ● | ○ | ○ | ○ | ○ | |
| 508/508HY/508RXH | | 2011- | | Airbag | RBG UDS | ● | ● | ● | ● | ○ | 10003 |
| 508/508HY/508RXH | | 2011- | | gearbox | BVA AM6 AT6 EURO5 | ● | ● | ● | ● | ● | 12006 |
| 508/508HY/508RXH | | 2011- | | ABS/traction control | ABS81 | ● | ● | ● | ● | ● | 05003 |
| 508/508HY/508RXH | | 2011- | | Engine ECU | DCM35 BR2 | ● | ● | ● | ● | ● | 04013, 12006 |
| 508/508HY/508RXH | | 2011- | | gearbox | CFC300P HY | ● | ● | ● | ● | ● | 05010, 12006 |
| 508/508HY/508RXH | | 2011- | | gearbox | CFC300P | ● | ● | ● | ● | ● | 05010, 12006 |
| 508/508HY/508RXH | | 2011- | | Engine ECU | MED17_4_2 | ● | ● | ● | ● | ● | 07011, 12006 |
| 508/508HY/508RXH | | 2011- | | Engine ECU | MEV17_4_2 | ● | ● | ● | ● | ● | 07011, 12006 |
| 508/508HY/508RXH | | 2011- | | Engine ECU | MM6KP | ● | ● | ● | ● | ● | 07011, 12006 |
| 508/508HY/508RXH | | 2011- | | Engine ECU | DCM35 HY | ● | ● | ● | ● | ● | 04013, 07001, 12006 |
| 508/508HY/508RXH | | 2011- | | Engine ECU | DCM34 P | ● | ● | ● | ● | ● | 04014, 04015, 12006 |
| 508/508HY/508RXH | | 2011- | | Engine ECU | HDI SID807 BR2 | ● | ● | ● | ● | ● | 04014, 04015, 12006 |
| 508/508HY/508RXH | | 2011- | | Engine ECU | EDC17CP42 | ● | ● | ● | ● | ● | 04007, 04014, 04015, 10000 |
| 508/508HY/508RXH | | 2011- | | ABS/traction control | 81 ESP | ● | ● | ● | ● | ● | 01002, 01005, 05003, 05006, 0006 |
| 508/508HY/508RXH | | 2011- | | Electric sencondary brake | FSE | ● | ● | ● | ● | ● | 01001, 01003, 01004 |
| 508/508HY/508RXH | | 2011- | | Under inflation detection | DSG | ● | ● | ● | ● | ○ | 02002, 02004, 02005, 02006, 02009, 02012 |
| 508/508HY/508RXH | | 2011- | | Built-in System Interface (BSI) | BSI2010 | ● | ● | ● | ● | ● | 03003, 03004, 10001 |
| 508/508HY/508RXH | | 2011- | | Switch module under the steering wheel (top of column) | COM2008P | ● | ● | ● | ● | ● | 05002 |
| 508/508HY/508RXH | | 2011- | | Electric steering lock | AVE | ● | ● | ● | ● | ● | 05009 |
| 508/508HY/508RXH | | 2011- | | Additional heating | CHAUFF_ADD | ● | ● | ● | ● | ● | 12006 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|------------------|-------------|-------|------|--|------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 508/508HY/508RXH | | 2011- | | Active damper electronic unit | BEBA | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Air conditioning | CLIM_REGULEE_UDS | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Anti-thdft alarm | ALARME | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Battery charge status | BECEB_GEN2 | ● | ● | ● | ● | ○ | |
| 508/508HY/508RXH | | 2011- | | Data communication ECU (RT6) | RT6 | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Discharger bulbs vertical and horizontal | LADCT | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Driver's seat memorizing unit | BDMC | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Electronic key reader | LCE | ● | ● | ● | ● | ○ | |
| 508/508HY/508RXH | | 2011- | | Engine relay unit | BSM_2010 | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Hands-free control unit | BML | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | High Head Vision | VTH_UDS | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Hybird mode selector | MCM | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Hybrid control ECU 1 | HCU1 | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Hybrid control ECU 2 | HCU2 | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Independent telematic unit (BTA) | BTA | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Instrument panel | COMBINE_UDS | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Main beams assistant ECU | RETRO_INT | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Matrix screen integral to the instrument | MATT_C_2010 | ● | ● | ● | ○ | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|------------------|-------------|-------|------|--|----------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 508/508HY/508RXH | | 2011- | | Matrix screen integral to the instrument | MATT_M_2010 | ● | ● | ● | ○ | ● | |
| 508/508HY/508RXH | | 2011- | | Motorised Boot ECU | COFFRE_MOTORISE | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Multifunction screen | EMF_A_UDS | ● | ● | ● | ○ | ● | |
| 508/508HY/508RXH | | 2011- | | Multifunction screen | EMF_C_UDS | ● | ● | ● | ○ | ● | |
| 508/508HY/508RXH | | 2011- | | Multiplexed control panel | FMUX | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Parking assistance | AAS_UDS | ● | ● | ● | ● | ○ | |
| 508/508HY/508RXH | | 2011- | | PLATINE DE PORTE | PDPF | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Power steering electric pump | GEP | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Radio amplifier | AMPLI_AUDIO | ● | ● | ● | ○ | ● | |
| 508/508HY/508RXH | | 2011- | | Rain and brightness sensor (CDPL) | PLUIE_LUMINOSITE_UDS | ● | ● | ● | ● | ○ | |
| 508/508HY/508RXH | | 2011- | | RD5 radio | RD5 | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Rear air conditioning | CLIM_AR | ● | ○ | ○ | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Seat belts not fastened LED unit (TNB) | TNB_2010 | ● | ○ | ○ | ○ | ● | |
| 508/508HY/508RXH | | 2011- | | Steering wheel with integral | VCI | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Supply protection and management | BPGA2010 | ● | ● | ● | ● | ○ | |
| 508/508HY/508RXH | | 2011- | | Telematic navigator | CRT_UDS | ● | ○ | ○ | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Traction battery ECU | TBMU | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Trailer relay unit | BSG_2010_RQ | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Voltage retaining device | DMTC | ● | ○ | ○ | ○ | ○ | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|------------------|-----------------|-------|---------------------------------------|-----------------------------------|----------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| 508/508HY/508RXH | | 2011- | | Widscreen wiper(left-hand side) | MOTEV_UDS | ● | ● | ● | ● | ● | |
| 508/508HY/508RXH | | 2011- | | Windscreen wiper(right-hand side) | MOTED_UDS | ● | ● | ● | ● | ● | |
| BIPPER | | | Engine / Gearbox | Engine ECU/Diesel | HDI_8DF2 | ● | ● | ● | ● | ● | 04012 |
| BIPPER | | | Driving assistance/Comfort | | Parking assistance | ● | ● | ● | ● | ○ | |
| BIPPER | | | | | Built-in system | ● | ● | ● | ● | ● | |
| BIPPER | | | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| BIPPER | | | Engine / Gearbox | Engine ECU/Petrol | KFV V34P | ● | ● | ● | ● | ● | |
| BIPPER | | | Engine / Gearbox | Engine ECU/Diesel | 8HS EDC16C34 | ● | ● | ● | ● | ● | |
| BIPPER | | | Engine / Gearbox | Gearbox | BVMP | ● | ● | ● | ● | ● | |
| BIPPER | | | Active and passive safety | | Control unit ABS | ● | ● | ● | ● | ● | |
| BIPPER | | | Active and passive safety | | Air-bag | ● | ● | ● | ● | ● | |
| BOXER | BOXER 3 | | Engine/Gearbox | | EDC17CP52 | ● | ● | ● | ● | | 04014 |
| BOXER | BOXER 3 | | Engine/Gearbox | | EDC17CP52 | ● | ● | ● | ● | | 04014 |
| BOXER | BOXER 3 Minibus | | Active and passive safety | ABS or ESP ECU | ESP8.0 | ● | ● | ● | ● | ● | 05003 |
| BOXER | BOXER 3 | | Active and passive safety | ABS or ESP ECU | ESP8.0 | ● | ● | ● | ● | ● | 05003, 05006 |
| BOXER | BOXER U5 | | Air conditioning | | WEBASTO additional teating | ● | | | ● | | |
| BOXER | BOXER_U5 | | Engines/automatic gearbox | Petrol | MM4.8P 2L Unleaded petrol | ● | ● | ● | ● | ● | |
| BOXER | BOXER_U5 | | Engines/automatic gearbox | Petrol | MM48P 2L essence plombee | ● | ● | ● | ● | ● | |
| BOXER | BOXER_U5 | | Engines/automatic gearbox | Petrol | MM48P 2L dual fuel(LPG) | ● | ● | ● | ● | ● | |
| BOXER | BOXER_U5 | | Engines/automatic gearbox | Diesel | 2.0L Bosch EDC15C7 | ● | ● | ● | ● | | |
| BOXER | BOXER_U5 | | Engines/automatic gearbox | Diesel | 2.2L Bosch EDC15C7 | ● | ● | ● | ● | | |
| BOXER | BOXER_U5 | | Engines/automatic gearbox | Diesel | 2.8L Bosch EDC15C7 | ● | ● | ● | ● | | |
| BOXER | BOXER_U5 | | Engines/automatic gearbox | | 4HP20 automatic gearbox | ● | | | ● | ○ | |
| BOXER | BOXER 3 | | Engine/Gearbox | | 4HU PUMA DCU102 | ● | ● | ● | ● | | |
| BOXER | BOXER 3 | | Engine/Gearbox | | 4HV PUMA DCU102 | ● | ● | ● | ● | | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-----------------|------|---------------------------------------|-------------|---------------------------------|-----------|------------|-------------|-----------|-------------|---------------------|
| BOXER | BOXER 3 | | Driving assistance/Comfort | | Additional heating | ● | ● | ● | ● | | |
| BOXER | BOXER 3 | | Driving assistance/Comfort | | Power steering | ● | ● | ● | ● | ○ | |
| BOXER | BOXER 3 | | Inform the driver/Audio/Communication | | Chronotachograph | ● | ● | ● | ● | | |
| BOXER | BOXER 3 | | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | |
| BOXER | BOXER 3 | | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| BOXER | BOXER 3 | | Inform the driver/Audio/Communication | | Telematic | ● | ● | ● | ● | | |
| BOXER | BOXER 3 | | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ● | |
| BOXER | BOXER 3 | | Driving assistance | | Parking assistance | ● | ● | ● | ● | ○ | |
| BOXER | BOXER 3 | | Driving assistance | | Pneumatic suspension | ● | ● | ● | ● | ● | |
| BOXER | BOXER 3 Minibus | | Engine/Gearbox | | 4HU PUMA DCU102 | ● | ● | ● | ● | | |
| BOXER | BOXER 3 Minibus | | Engine/Gearbox | | 4HV PUMA DCU102 | ● | ● | ● | ● | | |
| BOXER | BOXER 3 Minibus | | Driving assistance/Comfort | | Additional heating | ● | ● | ● | ● | | |
| BOXER | BOXER 3 Minibus | | Driving assistance/Comfort | | Power steering | ● | ● | ● | ● | ○ | |
| BOXER | BOXER 3 Minibus | | Inform the driver/Audio/Communication | | Chronotachograph | ● | ● | ● | ● | | |
| BOXER | BOXER 3 Minibus | | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | |
| BOXER | BOXER 3 Minibus | | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| BOXER | BOXER 3 Minibus | | Inform the driver/Audio/Communication | | Telematic | ● | ● | ● | ● | | |
| BOXER | BOXER 3 Minibus | | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ● | |
| BOXER | BOXER 3 Minibus | | Driving assistance / comfort | | Parking assistance | ● | ● | ● | ● | ○ | |
| BOXER | BOXER 3 Minibus | | Driving assistance / comfort | | Pneumatic suspension | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | | | Built-in systems interface(BSI) | ● | ● | ● | ● | ● | 03005 |
| EXPERT | EXPERT 2 | | Engine/Gearbox | Diesel | RHR SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015 |
| EXPERT | EXPERT 2 | | Engine/Gearbox | Diesel | RHL SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015 |
| EXPERT | EXPERT 2 | | Engine/Gearbox | Diesel | RHK SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|------|---------------------------------------|------------------|---|-----------|------------|-------------|-----------|-------------|--|
| EXPERT | EXPERT 2 | | Engine/Gearbox | Diesel | RHG SIEMENS SID 803 | ● | ● | ● | ● | ● | 04002, 04014, 04015 |
| EXPERT | EXPERT 2 | | Engine/Gearbox | Diesel | DCM3.5 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04019, 04020, 04021 |
| EXPERT | EXPERT 2 | | Active and passive safety | ABS or ESP ECU | ABS8_BOSCH | ● | ● | ● | ● | ● | 05003 |
| EXPERT | EXPERT 2 | | Active and passive safety | ABS or ESP ECU | ESP_BOSCH8 | ● | ● | ● | ● | ● | 05003 |
| EXPERT | EXPERT | | Engine/automatic gearbox | | AL4 autoadaptive automatic gearbox | ● | | ● | ● | ● | 07011 |
| EXPERT | EXPERT 2 | | Engine/Gearbox | Petrol | RFH MM6KP | ● | ● | ● | ● | ● | 07011 |
| EXPERT | EXPERT | | Air bags | | Air bag and seat belt | ● | | ● | | | |
| EXPERT | EXPERT | | Engine/automatic gearbox | Petrol | R6F MM4.8P | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT | | Engine/automatic gearbox | Petrol | RFN MM4.8P | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT | | Engine/automatic gearbox | Diesel | RHW BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT | | Engine/automatic gearbox | Diesel | RHX BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT | | Engine/automatic gearbox | Diesel | RHZ BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT | | Engine/automatic gearbox | Diesel | WJY LUCAS DCN2 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT | | Active safety | | BOSCH ABS5.3 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT | | | | Additional heating | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Driving assistance/Comfort | | Parking assistance | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Driving assistance/Comfort | | Additional heating | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Driving assistance/Comfort | Air conditioning | Air conditioning / Front air conditioning | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Driving assistance/Comfort | Air conditioning | Rear air conditioning | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Driving assistance/Comfort | | Power steering | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Driving assistance/Comfort | | Pneumatic suspension | ● | ● | ● | ● | | |
| EXPERT | EXPERT 2 | | Inform the driver/Audio/Communication | | Multi-function display | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ○ | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|------|---------------------------------------|------------------------------|----------------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| EXPERT | EXPERT 2 | | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | | |
| EXPERT | EXPERT 2 | | Inform the driver/Audio/Communication | | Hands Free Kit | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Inform the driver/Audio/Communication | Telematics | Data communication ECU | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Inform the driver/Audio/Communication | Telematics | RNEG radio navigation | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Engine/Gearbox | Diesel | 9HU BOSCH EDC16C3-EDC16C34 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Engine/Gearbox | Diesel | 9HT BOSCH EDC16C3 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Vehicle protection/Managem | | Alarm | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Active and passive safety | | Airbag ECU | ● | ● | ● | ● | ○ | |
| EXPERT | EXPERT 2 | | Visibility/Lightin | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| EXPERT | EXPERT 2 | | Visibility/Lighting/Signalling | | Steering wheel switching module. | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Active and passive safety | ABS or ESP ECU | ABS8.1 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 2 | | Active and passive safety | ABS or ESP ECU | ESP8.1 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Multifunction display | EMF_A | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Multifunction display | EMF_C | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Driver and passenger airbags | SAC_AUTOLIV | ● | ● | ● | ● | ○ | |
| EXPERT | EXPERT 3 | | | Anti-thdft alarm | ALARME | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Radio | AUTORADIO | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Engine relay unit | BSM | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Trailer relay unit | BSR | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Engine ECU | DCM3.5 BR2 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Engine ECU | EDC17C10 BR2 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Hands-free kit | KML | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|------|---------------------------|--|-------------------|-----------|------------|-------------|-----------|-------------|---------------------|
| EXPERT | EXPERT 3 | | | Bodywork conversion unit | BTC | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Type Under-Inflation Detection | DSG | ● | ● | ● | ● | ○ | |
| EXPERT | EXPERT 3 | | | gearbox | BVA AM6 AT6 EURO5 | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | High frequency | RHF | ● | ● | ● | ● | ● | |
| EXPERT | EXPERT 3 | | | Anti-slip mode selector | ASR | ● | ● | ● | ● | ● | |
| HOOGAR | | | Active and passive safety | ABS or ESP ECU | ESP MK60 | ● | ● | ● | ● | | 05003 |
| ION | ION | | | Instrument panel | METER | ● | ● | ● | ● | ● | 03001, 03002, 03004 |
| ION | ION | | | Built-in System Interface | ETACS | ● | ● | ● | ● | ● | |
| ION | ION | | | Electric motor ECU | MCU | ● | ● | ● | ● | ● | |
| ION | ION | | | Traction battery ECU | BMU | ● | ● | ● | ● | ● | |
| ION | ION | | | Onboard charger of the tratction barrery | | ● | ● | ● | ● | ● | |
| ION | ION | | | Electric vehicle management | EV_ECU | ● | ● | ● | ● | ● | |
| ION | ION | | | Traction battery cell electronics | CMU_01 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | Traction battery cell electronics | CMU_02 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | Traction battery cell electronics | CMU_03 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | Traction battery cell electronics | CMU_04 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | Traction battery cell electronics | CMU_05 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | Traction battery cell electronics | CMU_06 | ● | ○ | ○ | ● | ○ | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|----------------|----------------------------------|--|---------------------------|-----------|------------|-------------|-----------|-------------|-----------------------------------|
| ION | ION | | | Traction battery cell electronics | CMU_07 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | Traction battery cell electronics | CMU_08 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | Traction battery cell electronics | CMU_09 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | Traction battery cell electronics | CMU_10 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | Traction battery cell electronics | CMU_11 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | Traction battery cell electronics | CMU_12 | ● | ○ | ○ | ● | ○ | |
| ION | ION | | | ESP | ASC | ● | ● | ● | ● | ○ | |
| ION | ION | | | Power | EPS | ● | ● | ● | ● | ○ | |
| ION | ION | | | Steering wheel angle | SAS | ● | ● | ● | ● | ● | |
| ION | ION | | | Airbag | SRS | ● | ● | ● | ● | ● | |
| ION | ION | | | Gateway wiring | BSP | ● | ● | ● | ● | ○ | |
| ION | ION | | | Independent telematic | BTA | ● | ● | ● | ● | ● | |
| ION | ION | | | Radio | RDE | ● | ● | ● | ● | ● | |
| ION | ION | | | Air conditioning | HVAC | ● | ● | ● | ● | ● | |
| ION | ION | | | Air conditioning compressor and passeger compartment heating control | COMP_HTR | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | Driver information/Communication | | Under inflation detection | ● | ● | ● | ● | ○ | 02002, 02003, 02010, 02011, 02012 |
| PARTNER | PARTNER B9 | 1997- | engines/automatic gearbox | Diesel | EDC17C10_BR2 | ● | ● | ● | ● | | 04014, 04015, 04017, 04019 |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Diesel | EDC17C10_BR2 | ● | ● | ● | ● | | 04014, 04015, 04017, 04019 |
| PARTNER | PARTNER B9 | 1997- | engines/automatic gearbox | Diesel | HDI_SID807 | ● | ● | ● | ● | | 04014, 04015, 04019 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|----------------|---------------------------------------|-----------------------------|----------------------------------|-----------|------------|-------------|-----------|-------------|---------------------|
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Diesel | HDI_SID807 | ● | ● | ● | ● | | 04014, 04015, 04019 |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | Diesel | 9HT EDC16C3 | ● | ● | ● | ● | ● | 04014, 04020 |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | Diesel | 9HX EDC16C3 | ● | ● | ● | ● | ● | 04014, 04020 |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | Diesel | 9HZ EDC16C3 | ● | ● | ● | ● | ● | 04014, 04020 |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | Diesel | 9HS EDC16C3 | ● | ● | ● | ● | ● | 04014, 04020 |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | Diesel | 9HV EDC16C3 | ● | ● | ● | ● | ● | 04014, 04020 |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | Diesel | 9HW EDC16C3 | ● | ● | ● | ● | ● | 04014, 04020 |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Diesel | 9HW BOSCH EDC16C3 | ● | ● | ● | ● | | 04014, 04020 |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Diesel | 9HX BOSCH EDC16C3 | ● | ● | ● | ● | | 04014, 04020 |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Diesel | 9HT BOSCH EDC16C3 | ● | ● | ● | ● | | 04014, 04020 |
| PARTNER | PARTNER B9 | 1997- | Active and passive safety | ABS or ESP ECU | ESP 8.1 | ● | ● | ● | ● | ● | 05003 |
| PARTNER | | 2002.9-2002.10 | Active safety | | ESP 8.1 | ● | ● | ● | ● | ● | 05003, 05006 |
| PARTNER | | 2002.9-2002.10 | Active safety | | ESP BOSCH 5.7 | ● | ● | ● | ● | ● | 05005, 05012 |
| PARTNER | | 2002.9-2002.10 | Active safety | | ESP BOSCH 8 | ● | ● | ● | ● | ● | 05005, 05012 |
| PARTNER | | 1997-2002.9 | Engines/automatic gearbox | Petrol | HFX BOSCH M7.4.4 | ● | ● | ● | ● | | 07011 |
| PARTNER | | 1997-2002.9 | Engines/automatic gearbox | Petrol | KFW SAGEM S2000 | ● | | ● | ● | ● | 07011 |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | Petrol | N6A ME745 | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | Petrol | N6B ME745 | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | Petrol | NFU ME745 | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | Petrol | NFR ME745 | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | Engine/Gearbox | | Multiplexed additive adding | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | Driver | | Air conditioning | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | Driver | | Power steering | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | | | Built-in systems interface (BSI) | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | Inform the driver/Audio/Communication | Multitunction display (EMF) | EMF_A | ● | ● | ● | ● | ○ | |
| PARTNER | PARTNER B9 | 1997- | Inform the driver/Audio/Communication | Multitunction display (EMF) | EMF_C | ● | ● | ● | ● | ○ | |
| PARTNER | PARTNER B9 | 1997- | Inform the driver/Audio/Communication | | Radio | ● | ● | ● | ● | ○ | |
| PARTNER | PARTNER B9 | 1997- | Inform the driver/Audio/Communication | | Instrument panel | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|----------------|---------------------------------------|----------------|----------------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| PARTNER | PARTNER B9 | 1997- | Inform the driver/Audio/Communication | | CD player | ● | ● | ● | ○ | ○ | |
| PARTNER | PARTNER B9 | 1997- | Inform the driver/Audio/Communication | Hands Free Kit | Portable unit | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | Inform the driver/Audio/Communication | | Steering wheel switching module. | ● | ● | ● | ● | ○ | |
| PARTNER | PARTNER B9 | 1997- | Inform the driver/Audio/Communication | Telematics | RNEG radio navigation | ● | ● | ● | ● | ● | |
| PARTNER | PARTNER B9 | 1997- | Vehicle protection/Management | | Alarm | ● | ● | ● | ● | ○ | |
| PARTNER | PARTNER B9 | 1997- | Active and passive safety | | Air bag | ● | ● | ● | ● | ○ | |
| PARTNER | PARTNER B9 | 1997- | Visibility/Lighting | | Rain Sensor | ● | ● | ● | ○ | ○ | |
| PARTNER | PARTNER B9 | 1997- | Active and passive safety | ABS or ESP ECU | ABS 8.1 | ● | ● | ● | ● | ● | |
| PARTNER | | 1997-2002.9 | | | Built-in systems interface(BSI) | | ● | ● | | | |
| PARTNER | | 1997-2002.9 | Driver information/Communication | | Radio PHILIPS | | ● | ● | | ● | |
| PARTNER | | 1997-2002.9 | Driver information/Communication | | Radio CLARION | | ● | ● | | ● | |
| PARTNER | | 1997-2002.9 | Driver information/Communication | | CD player | ● | ● | ● | ● | | |
| PARTNER | | 1997-2002.9 | Driver information/Communication | | Instrument panel | ● | ● | ● | ● | | |
| PARTNER | | 1997-2002.9 | Air bags | | Air bag and seat belt | | ● | ● | ○ | ○ | |
| PARTNER | | 1997-2002.9 | Engines/automatic gearbox | Petrol | HDY BOSCH MA3.1 | ● | ● | ● | ● | ● | |
| PARTNER | | 1997-2002.9 | | | Additional heating | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | driving assistance / Comfort | | Parking assistance | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | driving assistance / Comfort | | Additional heating | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | | | Built-in systems interface(BSI) | ● | ● | ● | ● | | |
| PARTNER | | 2002.9-2002.10 | | | Alarm | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|------------------|----------------------------------|--------------------|----------------------------------|-----------|------------|-------------|-----------|-------------|------------------|
| PARTNER | | 2002. 9-2002. 10 | Driver information/Communication | Display/Telematics | AMF | ● | ● | ● | ● | ● | |
| PARTNER | | 2002. 9-2002. 10 | Driver information/Communication | Display/Telematics | RT3 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002. 9-2002. 10 | Driver information/Communication | | radio | ● | ● | ● | ● | ● | |
| PARTNER | | 2002. 9-2002. 10 | Driver information/Communication | | CD player | ● | ● | ● | ● | | |
| PARTNER | | 2002. 9-2002. 10 | Driver information/Communication | | Instrument panel | ● | ● | ● | ● | ● | |
| PARTNER | | 2002. 9-2002. 10 | Driver information/Communication | | steering wheel switching module. | ● | ● | ● | ● | ○ | |
| PARTNER | | 2002. 9-2002. 10 | | | air bags | ● | ● | ● | ○ | ○ | |
| PARTNER | | 2002. 9-2002. 10 | Visibility/Lighting/Signalling | | Steering wheel switching module. | ● | ● | ● | ● | ○ | |
| PARTNER | | 2002. 9-2002. 10 | Visibility/Lighting/Signalling | | Rain/brightness sensor | ● | ● | ● | ○ | ○ | |
| PARTNER | | 1997-2002. 9 | Engines/automatic gearbox | Petrol | K6D SAGEM S2000 | ● | | ● | ● | ● | |
| PARTNER | | 1997-2002. 9 | Engines/automatic gearbox | Petrol | KFX BOSCH MP7. 3 | | ● | ● | | ● | |
| PARTNER | | 1997-2002. 9 | Engines/automatic gearbox | Petrol | N6A BOSCH ME7. 4. 4 | ● | ● | ● | ● | ● | |
| PARTNER | | 1997-2002. 9 | Engines/automatic gearbox | Petrol | NFU BOSCH ME7. 4. 4 | ● | ● | ● | ● | ● | |
| PARTNER | | 1997-2002. 9 | Engines/automatic gearbox | Petrol | N6A BOSCH ME7. 4. 5 | ● | ● | ● | ● | ● | |
| PARTNER | | 1997-2002. 9 | Engines/automatic gearbox | Petrol | N6B BOSCH ME7. 4. 5 | ● | ● | ● | ● | ● | |
| PARTNER | | 1997-2002. 9 | Engines/automatic gearbox | Petrol | NFU BOSCH ME7. 4. 5 | ● | ● | ● | ● | ● | |
| PARTNER | | 1997-2002. 9 | Engines/automatic gearbox | Diesel | RHY BOSCH EDC15C2 | ● | ● | ● | ● | ● | |
| PARTNER | | 1997-2002. 9 | Engines/automatic gearbox | Diesel | WJY LUCAS DCN2 | ● | ● | ● | ● | ● | |
| PARTNER | | 1997-2002. 9 | Engines/automatic gearbox | Diesel | WJZ LUCAS DCN2 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002. 9-2002. 10 | engines/automatic gearbox | Petrol | HFX MM4. 8P | ● | ● | ● | ● | ● | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|----------------|----------------------------------|----------------------------------|--------------------|-----------|------------|-------------|-----------|-------------|--|
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Petrol | KFW SAGEM S2000PM1 | ● | ● | ● | ● | | |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Petrol | KFW SAGEM S2000PM2 | ● | ● | ● | ● | | |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Petrol | N6A BOSCH ME7.4.4 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | Active safety | | BOSCH ABS5.3 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | Active safety | | ABS BOSCH 8 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Petrol | NFU BOSCH ME7.4.4 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Petrol | N6A BOSCH ME7.4.5 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Petrol | N6B BOSCH ME7.4.5 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Petrol | NFU BOSCH ME7.4.5 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Petrol | KFW J34P | ● | ● | ● | ● | ● | |
| PARTNER | | 1997-2002.9 | Engines/automatic gearbox | Diesel | RHY SIEMENS SID801 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Diesel | WJY LUCAS DCN2 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | Diesel | RHY SIEMENS SID801 | ● | ● | ● | ● | ● | |
| PARTNER | | 2002.9-2002.10 | engines/automatic gearbox | LPG /GNV | SAGEM SAX500 | ● | ● | ● | ● | | |
| PARTNER | | 2002.9-2002.10 | Active safety | | ABS 8.1 | ● | ● | ● | ● | ● | |
| RCZ | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | DCM3.5 | ● | ● | ● | ● | ● | 04010, 04014, 04015, 04019, 04020, 04021 |
| RCZ | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | EDC17C10_BR2 | ● | ● | ● | ● | ● | 04014, 04015, 04017, 04019 |
| RCZ | | | Engine/Gearbox | Engine ECU→ Petrol | EDC17C10_BR2 | ● | ● | ● | ● | ● | 04014, 04015, 04017, 04019 |
| RCZ | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | HDI_SID807_BR2 | ● | ● | ● | ● | ● | 04014, 04015, 04017, 04019 |
| RCZ | | 2007- | Engine /Gearbox | Engine ECU→ Diesel | HDI_SID807 | ● | ● | ● | ● | ● | 04014, 04015, 04019 |
| RCZ | | 2007- | Engine /Gearbox | Multiplexed additive adding pump | POMPE_MUX_TI | ● | ● | ● | ● | ● | 04026 |
| 301 | | 2013 | Built-in Systems Interface (BSI) | | BSI2010 | ▲ | ▲ | ▲ | ▲ | ▲ | 03003, 03004, 10001 |
| 301 | | 2013 | ABS or ESP ECU | | ABSMK100 | ▲ | ▲ | ▲ | ▲ | ▲ | 09003, 06007, 02010 |
| 301 | | 2013 | ABS or ESP ECU | | ESPMK100 | ▲ | ▲ | ▲ | ▲ | ▲ | 09003, 06006, 02010, 05001 |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|------|-------------------------------------|-------------|----------------------|-----------|------------|-------------|-----------|-------------|-----------------------------------|
| 301 | | 2013 | Multifunction screen | | EMF_C_UDS | ▲ | ▲ | ▲ | | ▲ | |
| 301 | | 2013 | Switch module at the steering wheel | | HDC | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 301 | | 2013 | Automatic gearbox AL4/AT8 | | BVA_AL4 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 301 | | 2013 | Engine ECU | | V46 21 | ▲ | ▲ | ▲ | ▲ | ▲ | 11002, 07011 |
| 301 | | 2013 | Engine ECU | | EDC17C10 BR2 | ▲ | ▲ | ▲ | ▲ | ▲ | 07011, 07012, 07013, 07014, 07015 |
| 301 | | 2013 | Engine ECU | | V46 | ▲ | ▲ | ▲ | ▲ | ▲ | 07011 |
| 301 | | 2013 | Airbag | | RBG UDS | ▲ | ▲ | ▲ | ▲ | ○ | |
| 301 | | 2013 | Electric power steering | | DAE | ▲ | ▲ | ▲ | ▲ | ○ | |
| 301 | | 2013 | Radio | | RDE | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 301 | | 2013 | Radio | | RD45 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 301 | | 2013 | Parking assistance | | AAS UDS | ▲ | ▲ | ▲ | ▲ | ○ | |
| 301 | | 2013 | Siren | | SIR | ▲ | ▲ | ▲ | ▲ | ○ | |
| 301 | | 2013 | Instrument panel | | COMBINE UDS | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 301 | | 2013 | Trailer relay unit | | BSG 2010 RQ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 301 | | 2013 | Multiplexed additive pump | | PADDGO | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 301 | | 2013 | Automatic gearbox AL4/AT8 | | MAPS_UDS | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 301 | | 2013 | Engine ECU | | ME745 EC5 | ▲ | ▲ | ▲ | ▲ | ▲ | 07011 |
| 301 | | 2013 | Electric power steering | | DAE_A515 | ▲ | ▲ | ▲ | ▲ | ○ | |
| 2008 | | 2013 | Built-in Systems Interface | | BSI2010 | ▲ | ▲ | ▲ | ▲ | ▲ | 03003, 03004, 10001 |
| 2008 | | 2013 | Engine ECU | | EDC17C10 BR2 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Engine ECU | | MEV17 4 2 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Engine ECU | | HDI SID807 BR2 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Engine ECU | | V46 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | ABS or ESP ECU | | ABSMK100 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | ABS or ESP ECU | | ESPMK100 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | gearbox | | BVA AL4 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | gearbox | | CFC300P | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | gearbox | | MAPS UDS | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Telematics | | SMEG | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Rain and brightness sensor | | PLUIE_LUMINOSITE_UDS | ▲ | ▲ | ▲ | ▲ | ○ | |
| 2008 | | 2013 | Siren | | SIR | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Anti-theft alarm | | MUS | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | audio amplifier | | AMPLI AUDIO | ▲ | ▲ | ▲ | ○ | ▲ | |
| 2008 | | 2013 | Air bag | | RBG UDS | ▲ | ▲ | ▲ | ▲ | ○ | |
| 2008 | | 2013 | External CD player | | CDE | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Battery charge status unit | | BECE_GEN2 | ▲ | ▲ | ▲ | ▲ | ○ | |
| 2008 | | 2013 | Instrument panel | | COMBINE UDS | ▲ | ▲ | ▲ | ▲ | ▲ | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|------|--|-------------|----------------------|-----------|------------|-------------|-----------|-------------|---------------------|
| 2008 | | 2013 | Multiplexed control panel | | FMUX | ▲ | ▲ | ▲ | ○ | ▲ | |
| 2008 | | 2013 | Trailer relay unit | | BSG 2010 RQ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Switch module under the steering wheel (Top of column) | | COM2008P | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Radio | | RDE | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Electric power steering | | DAE | ▲ | ▲ | ▲ | ▲ | ○ | |
| 2008 | | 2013 | Steering wheel with integral controls (VCI) | | VCI | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Air conditioning | | TDC RFTA MUX | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Parking aid | | AAS UDS | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Matrix screen integral to the instrument panel | | MATT_C_2010 | ▲ | ▲ | ▲ | ○ | ▲ | |
| 2008 | | 2013 | Independent telematic unit (BTA) | | BTA | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 2008 | | 2013 | Multiplexed additive pump | | PADDGO | ▲ | ▲ | ▲ | ▲ | ○ | |
| 208(Ai91) | | 2013 | Built-in Systems Interface | | BSI2010 | ▲ | ▲ | ▲ | ▲ | ▲ | 03003, 03004, 10001 |
| 208(Ai91) | | 2013 | Engine ECU | | ME749 EC5 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Engine ECU | | V34.4 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Engine ECU | | V34.5 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | ABS or ESP ECU | | ABSMK100 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | ABS or ESP ECU | | ESPMK100 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | gearbox | | CFC300P | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | gearbox | | BVA AL4 | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | gearbox | | MAPS UDS | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Parking assistance | | AAS UDS | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | External CD player | | CDE | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Telematics | | SMEG | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Switch module under the steering wheel (Top of column) | | COM2008P | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Air conditioning | | TDC RFTA MUX | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Radio | | RDE | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Rain and brightness sensor | | PLUIE_LUMINOSITE_UDS | ▲ | ▲ | ▲ | ▲ | ○ | |
| 208(Ai91) | | 2013 | Air bag | | RBG UDS | ▲ | ▲ | ▲ | ▲ | ○ | |
| 208(Ai91) | | 2013 | Multiplexed control panel | | FMUX | ▲ | ▲ | ▲ | ○ | ▲ | |

| Vehicle Type | Sub Vehicle | YEAR | Menu | System Name | ECUNAME | Ecu Info. | Read Codes | Erase Codes | Live Data | Active Test | Special Function |
|--------------|-------------|------|---|-------------|-------------|-----------|------------|-------------|-----------|-------------|------------------|
| 208(Ai91) | | 2013 | Electric power steering | | DAE | ▲ | ▲ | ▲ | ▲ | ○ | |
| 208(Ai91) | | 2013 | Steering wheel with integral controls (VCI) | | VCI | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Instrument panel | | COMBINE UDS | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Siren | | SIR | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Anti-theft alarm | | MUS | ▲ | ▲ | ▲ | ▲ | ▲ | |
| 208(Ai91) | | 2013 | Independent telematic unit (BTA) | | BTA | ▲ | ▲ | ▲ | ▲ | ▲ | |

Specil_Function

| Index | Specil Function Name | Index | Specil Function Name |
|-------|--|-------|---|
| 01001 | Cable Tensioning | 01002 | Deactivation of the automatic application of the Electric Parking Brake Function |
| 01003 | Electric Parking Brake Calibration | 01004 | Put In Fitting / Removal Position |
| 01005 | Reactivation of automatic application of the Electric Parking Brake | 02001 | Change of Tyre Fit |
| 02002 | Valve Search Faulty | 02003 | Deactivation / Activation Of The Tyre Under-inflation Detection Function |
| 02004 | Erasing Of The Secondary Wheels | 02005 | Initialisation of a single wheel transmitter module |
| 02006 | Initialisation of the Wheel Transmitter Modules | 02007 | Program Additional Wheel Set |
| 02008 | Programming of The Wheel Sensors | 02009 | Read Wheel Transmitter Module Identifiers |
| 02010 | Valve Programming Check | 02011 | Write Identifiers By Exciting Wheel Transmitter Modules |
| 02012 | Write Wheel Transmitter Module Identifiers By References | 02013 | Tyre above specification |
| 03001 | "Arduous" Maintenance Schedule | | |
| 03002 | "Normal" Maintenance Schedule | 03003 | Maintenance |
| 03004 | Maintenance Indicator Reset | 03005 | Maintenance Limit |
| 03006 | Reset Maintenance Information | 03007 | Service Indicator |
| 03008 | Service Information Reset | 04001 | Additive Circuit Pipe And Pump Replacement |
| 04002 | Additive ECU | 04003 | Additive Type Configuration |
| 04004 | Additive Tank Top Up Or Replacement (Low Additive Level Led Illuminated) | 04005 | Cleaning Or Replacement Of The Particulate Emission Filter |
| 04006 | Configuration Of The Additive ECU | 04007 | Configuration Of The Amount Of Additive In The Particle Filter |
| 04008 | Configuration Of The Quantity Of Additive Present In The Particle Emission Filter | 04009 | Filling Of The Additive Reservoir Or Pouch |
| 04010 | Filling Of The Diesel Additive Adding Reservoir | 04011 | Filling Of The Reservoir, Lighting Of The Low Additive Level Warning Light |
| 04012 | Forced Regeneration Of The Particle Emission Filter | 04013 | Forced Regeneration Of The Particle Filter, Vehicle Stationary |
| 04014 | Forced Regeneration Vehicle Moving | 04015 | Forced Regeneration Vehicle Stationary |
| 04016 | Particle Filter Replacement | 04017 | Programming Of The Quantity Of Additive Remaining In The Reservoir |
| 04018 | Programming Of The Total Additive Quantity | 04019 | Programming Of The Total Quantity Of Additive Injected Into The Particulate Emission Filter |
| 04020 | Replacement Of The Particle Emission Filter | 04021 | Replacement Of The Diesel Additive Reservoir, Of The Pump Or Of The Pipes |
| 04022 | Replacement Of The Additive ECU | 04023 | Replacement Or Filling Of The Diesel Additive Tank |
| 04024 | Filling Of The Additive Reservoir | 04025 | Replacement Of The Additive Adding Ecu |
| 04026 | Replacement Of The Additive Pump | 04027 | Replacement Of The Ecu With Reading / Writing Of The Adaptive Data |
| 04028 | Replacement Of The Ecu Without Reading / Writing Of The Adaptive Data | 04029 | Replacement Of The Metering Pump Or Replacement Of The Reservoir |
| 04030 | Replacement Of The Particle Emission Filter And Work On The Additive Adding Circuit | 05001 | Calibration Of The Gyrometer / Accelerometer Sensor |
| 05002 | Calibration Of The Steering Wheel Angle Sensor : C2, C3, C3 Pluriel, New Look C5 With Esp Mk60 | 05003 | Calibration Of The Steering Wheel Angle Sensor |
| 05004 | Clutch Pedal Position Sensor Calibration | 05005 | De-Calibration Of The Steering Wheel Angle Sensor |
| 05006 | Longitudinal Acceleration Sensor Calibration | 05007 | Replacement Of The Paddles At The Steering Wheel |
| 05008 | Master Cylinder Pressure Sensor Programming | 05009 | Programming Of The Immobiliser Code For The Electric Steering Lock |
| 05010 | Resetting Of The Paddles At The Steering Wheel Counter | 05011 | Steering Column Functions |
| 05012 | Steering Wheel Angle Sensor Calibration | 06001 | Bleeding |

| Index | Specil Function Name | Index | Specil Function Name |
|-------|--|-------|--|
| 06002 | Bleeding Of The Hydraulic Block ABS8.0 | 06003 | Bleeding Of The Hydraulic Block ASR8.0 |
| 06004 | Bleeding Of The Hydraulic Unit Regulation Circuit | 06005 | Bleeding Of The Precharge Pump Circuit |
| 06006 | Bleeding Of The Hydraulic Circuit | 06007 | Bleeding Of The Hydraulic Block ABS MK100 |
| 07001 | Initialisation of Diesel Injector | 07002 | Initialisation of The Air Flow Sensor |
| 07003 | Initialisation of The Ecu Supply | 07004 | Initialisation Of The EGR Butterfly |
| 07005 | Initialisation Of The EGR Valve | 07006 | Initialisation Of The Gearbox Actuator |
| 07007 | Initialisation Of The Oxygen Sensor | 07008 | Initialisation Of The Turbocharger Turbine Valve 2 (Vt2) |
| 07009 | Injection Ecu Initialisation Procedure | 07010 | Re-Centring Of Autoadaptive Systems |
| 07011 | Initialising The Autoadaptives | 07012 | Classification of injector 1 |
| 07013 | Classification of injector 2 | 07014 | Classification of injector 3 |
| 07015 | Classification of injector 4 | 07016 | Classification of the 4 injectors |
| 08001 | Overall check of the sensors | | |
| 09001 | Configuration | 09002 | Automatic configuration |
| 09003 | Manual configuration | 09004 | Customer configuration |
| 09005 | Vehicle configuration | 09006 | Configuration of the personalisation menu |
| 09007 | Configuration of options | 09008 | Radio configuration |
| 09009 | Antenna configuration | 09010 | VIN configuration |
| 09011 | Configuration of the instrument panel | 09012 | Configuration of the telematic unit |
| 09013 | Juke-box | 09014 | Services and associated telephone numbers |
| 09015 | Emergency battery | 09016 | ECU downloading |
| 09017 | Write VIN | 09018 | ECU configuration |
| 10001 | Key programming | 10002 | Programming / matching |
| 10003 | Locking/Unlocking | 10004 | Routine |
| 11001 | Oil wear counter | 11002 | Accelerator pedal initialisation |
| 12001 | Replacement of the automatic gearbox without its ECU | 12002 | Replacement of the ECU without the automatic gearbox |
| 12003 | Replacement of the automatic gearbox and its ECU | 12004 | Replacement of the ECU |
| 12005 | Writing of the alcohol content | 12006 | Replacement parts |